

**User Manual**

First of all, thank you for choosing our products, please check the attachments.

**Step 1: Download V30 APP on the mobile phone**

- ① Power adapter → Power interface → Power / reset button
- ② Scan "V30" in the Appstore store or search "V30" in the Appstore store
- ③ Power adapter → Power interface → Power / reset button

**Step 2: Connect the camera**

Interface: ① Power adapter ② Power interface ③ Power / reset button

Equipment starts, voice prompt to establish AP hotspots. Then open the mobile wireless Settings. Find my WiFi signal in the beginning, select and link to connect.

④ Open the V30 Settings and enter the wireless AP

⑤ Open the camera client

⑥ Open in the top right corner of the camera client, click on the camera icon to enter the camera settings

⑦ The device can be checked on the mobile phone. If the computer client has prompted a connection, click "OK". If there is no connection, click "Check again".

⑧ Please note the device IP address and port number, and record it for future reference. If the device IP address is not displayed, click "Check again".

⑨ Click "Device configuration" and enter the device configuration interface. Please note the device IP address and port number, and record it for future reference. If the device IP address is not displayed, click "Check again".

⑩ Please note the device IP address and port number, and record it for future reference. If the device IP address is not displayed, click "Check again".

⑪ Click "Device configuration" and enter the device configuration interface. Please note the device IP address and port number, and record it for future reference. If the device IP address is not displayed, click "Check again".

⑫ Check if the computer graphics card is installed. If not installed, click "Install driver" and follow the instructions to install the driver. If the graphics card is already installed, click "Next".

⑬ Click "Next" and follow the instructions to complete the installation.

⑭ After connecting the device, you can configure it. The main configuration functions are as follows:

**Device settings**

- ⑮ Device configuration
- ⑯ Device monitoring
- ⑰ Device upgrade

**More functions**

- ⑯ Push notification Settings
- ⑰ Software photo albums
- ⑱ Select the server area
- ⑲ Software password settings
- ⑳ Alert the software
- ㉑ Fix the software

**Equipment management**

Click on my device to change the Settings: Remove equipment, Edit equipment, Alarm switch, Warning message.

## FCC Warning

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

**Note:** This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- ▶ -Reorient or relocate the receiving antenna.
- ▶ -Increase the separation between the equipment and receiver.
- ▶ -Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- ▶ -Consult the dealer or an experienced radio/TV technician for help.

The distance between user and device should be no less than 20cm.