


Quick Start Guide



Quick Getting Started

Step 1: Connect Power: The sensor' s default setting has finished the power connected. The receiver can remain connected to AC power all the time, or it can operate with the installation of three (3) AA batteries.(Batteries not included)


Step 2: Set channel and sensitivity. The sensor will arrive pre-configured to a default channel and sensitivity setting if you buy the set of the sensor and receiver together. You will only need to reconfigure the settings if you want to change to a different setting, or if you purchased only the sensor without the receiver to expand it. The channel and sensitivity switches can be found inside the sensor. (How to set, please read the detail instruction part 2.2)

Step 3: Pairing: The sensor will arrive pre-configured to a default pairing setting if you buy the set of the sensor and receiver together. You will only need to reset the pairing if you want to change to a different setting, or if you purchased only the sensor without the receiver to expand it. For the full steps to the complete pairing method, please read the detailed manual.

Step 4: Charge the sensor. The sensor can continue to work up to 12 months after it has been fully charged. However, sensors are only charged to about 20% power when they leave our factory so you will need to charge it before installing.

Step 5: Install the sensor. After the sensor is fully charged, you can install the sensor in an outdoor setting where you want to detect motion. You can do this with the included screwdriver. For better security, you can adjust the angle of the sensor eye by moving the ball-joint after you' ve completed installation.

Step 6: After you have successfully installed the sensor, you will be able to use the detection function. Remember that the receiver is multifunctional and that you will need to configure your other settings, including your time settings, alarm settings, and melodies if you want to use them.







Rotate to turn the screw

Best Customer Service

This driveway alarm is a multifunctional technological product, and so some customers will experience some difficulty in using it. Please feel free to contact us if you encounter any problems with your system. We are dedicated to providing 100% quality service for our customers.



Customer Service Email: support@wulooofficial.com. Facebook page: @WulooOfficial.

We will do our best to reply to you within 12 business hours.

Model;WL-T1905

FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

-- Reorient or relocate the receiving antenna.

-- Increase the separation between the equipment and receiver.

-- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

-- Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.