

SPECIFICATIONS

Power Supply	12V	Dimming Ty pe	touch dimmer
Lamp Illumination	>1000LUX	Power wattage	9W
CRI	>80Ra	Luminous Flux	>400Lm
Lamp Color Tempsrature	Cold light: 5500K±500K	Warm light: 3000K±280K	Natural Light: 4200K±400K

Thank you for purchasing our products Toguarantee your rights, please fill in this from property, Thank you Name

Address Telephone

Item number

Invoice number Purchase date

Note: this field requires the dealers seal!


Warranty Card

Applicable for

- * Since buying date the user enjoys one year free repair services under normal use. After one year, will be charged according to each component
- * In case change component part will be charged according to our
- company's component part cost list. * The following situations not free repair in warranty period 1)Damage caused by natural earthquake,rat disaster,and unnormal use
- 2)Damage caused in transportation fall, and unproper storage. 3)Consumab e component, such as spare parts, batteries, light bu bs, etc. Warranty Information records is not complete, no purchase date, no buying shop seal, etc. 5)Featured using environment, such as humidity, su fur area, high saity and the ship, elc, easy corrosion area
- 6)Using not according to the instructions 7)Spec al offer
- * When return to factory for repair the user should make sure the LED lamp packed properly to avoid any damage during transportation
- * Factory not responsible for the damages caused by the user themself unproper disassemble

- * Do not self-disassemble the product,to avoid any electric shock * Please use supplier's specified edapter and power socket,
- to maintain normal working * Please do not over adjusting the joint activity parts,
- * Please do not put the lamps on the unstable desk to avoid the lamps
- * Please do not put the lamp into high temperature or high-humidity
- environment


 * Please do not look at the LED tight source straightly,
- * In case below conditions occur please pull out the power cord
- * If neaded, please call for support staff:
- *The power cord or power plug break *The lamp holderdamp or rain
- *The shell and joint activities of the lamp holder breaks *The lamp holder smokes or sparks *The abnormal flickering or break of the LED light bulb




- * Smart wireless charger, it cen charge the smart watches and cell phones which is QI wireless charging standard
- * High quality imitated leather design, can be used for long time Advenced precision etching technology, to show more realistic imitated leather effection.
- * Touchable sliding for brightness, make it more convenient * 5-grade brightness meet different lighting requirements.
- * 3 color temperature to choose.(Cold light, Warm light, Natural light)

USE MANUAL

* Calendar.



* Insert the adaptor head into the socket behind the lamp



* The range of activity for lamp




* Lamp ann can be fold-able to 90° angle * Please ho d the lamp base when you adjust lamp arm angle



* Lamp head can be fod-abe to 150° (It may be broken if you over-adjust)

REPLACEMENT BATTERY



DISPLAY SCREEN BRIGHTNESS ADJUSTMENT




* Once you connect the power adapter the screen will default the highest brightness * Then press this key and choose

* 3 step brightness adjustment

the suitable brightness you like

OPERATION GUIDE



* Calendar and alarm setting

* Date and Time setting 1.In normal mode,press "set" key to achieve setting functions, press against to move next, sequence

Hour-Minute Year-Month Day 2. Press "up" and "down" to setting, week changes automatically when

date change. 3. In setting mode press mode or stop operat on in one munite to exit setting, and display time. 4. In normal mode, press "down" key to switch between 12H or 24H


Snooze function setting 1. In normal mode, press "mode" key to active alarm setting. 2.In alarm mode, press "set" key to set the alarm time, sequence: Hour-Munite Snooze Music-Exit.

3. Press "up"and down to setting 4.In alarm mode, press "up" and "down" to turn on/offa arm and snooze function, press again to achieve next function, sequence alarm on snoozeon a arm off-snooze off 5.When come to alarm t me, will ring 1 munite, then snooze and ring again Press any key to off alarm.


* Temperature switch In normal mode, press "down" key to switch between "F and "C disp ay.

WIRELESS CHARGING INSTRUCTIONS

Put phone with QI technical standard on the lamp base surface for charging, once light indicater turns to red and phone screen shows connecting that phone means charging successfully; If phone doesn't show connecting status, pease check phone whether put to the wireless charging area correctly, or put phone on the base again, if still no working, kindly check the devices whether with QI technical




* Lamp indicater light in red means that phone is charging status



The red light flashing and start charging

* The green light will light up when mobile phone is full charge The cell phone battery symbol will also disp ey a full charge stete (Only own function of wireless charging of mobile devices have a state of charge indicator function, there is no this indicator function if the mobile phone is equipped with a receiver when c arg ng)



Green light, the charging is compete

FCC Statement

This device complies with part 18 of the FCC Rules. Operation is Subject To the following two conditions:

(1) This device may not cause harmful interference, and

(2) this devicemust accept any interference received, including interference that may cause undesired operation. Changes or modifications not explicitly approved by the partyresponsible for compliance could void the user's authority tooperate this equipment. Note: this equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 18 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and canradiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference toradio or television reception, which can be determined by turning the equipment off and on, the user is encouraged totry to correct the interference by one or more of the following measures: Reorient or relocate the receiving antenna.

(1) Increase the separation between the equipment and receiver. (2) Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

(3) Consult the dealer or an experienced radio/TV technician for

The equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. During the operation of device a distance of 15 cm surrounding the device and 20 cm above the top surface of the device must be respected.

This device complies with Part 18 of the FCC Rules. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

• Increase the separation between the equipment and any other

• Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.