

正面

Minoston®

Z-Wave Mini Plug

• MP21Z •

Power: 120V, 60Hz Loading: 10 Amp Max Resistive Frequency: 908.4MHz Temperature Range: 32-104° F (0-40° C)

Indoor use in dry location



Smart outlet

Can remotely turn On/Off the connected devices.

Program button

Press 1x: On/Off Press 3x: Z-Wave Network configuriation.

Features:

- 1. Z-Wave on/off control.
- 2. Z-Wave controlled AC outlet for standard incandescent lighting, CFL/LEDs, fans or small appliances(1250W Resistive Max).
- 3. Grounded 3-wire power connection for safety.
- 4. Remembers and restores on/off status after power failure.
- 5. Built-in Z-Wave Plus signal repeater to extend network range.
- 6. S2 security and 500 Z-Wave chip for reliable wireless communication.
- 7. Work with all certificated Z-Wave controllers.



This product can be included and operated in any Z-Wave network with other Z-Wave certified devices from other manufacturers and/or other applications. All non-battery operated nodes within the network will act as repeaters regardless of vendor to increase the reliability of the network. This Device supports Lifeline (association group 1) supporting 1 node for lifeline communication.

Group 1 must be assigned the Node ID of the primary controller where unsolicited notifications will be sent. The Z-Wave controller should set this association automatically after inclusion.

Lifeline association only supports the "Device Reset Locally" function.

Notes:

1. Plug the device you want to control into the Z-Wave Smart plug controlled outlet. NOTE: Plug directly into the outlet, do not use with extension cords.



2. Your device may need to be within 100 feet of the controller to be included. If so, include the device to the network within 10 feet of the controller and relocate it to the desired position in your home. Be sure to refresh the network if the device is included in this manner.





Z-Wave Network Configuration

Adding Device To Z-Wave Network

- 1. Follow the instructions for your Z-Wave certified controller to add a device to the Z-Wave network.
- 2. Once the controller is ready to add your device, press the Manual/ Program button on the smart plug 3 times quickly. The blue LED will blink quickly. Auto-add mode: LED will blink within 30 seconds after first plugged in.

Now, you have complete control to turn your fixture ON/OFF according to groups, schedules and interactive automation programmed by your controller. If your Z-Wave certified controller features remote access, you can control your fixture from your mobile devices.

Again: If you have issues with pairing/including, please move the device as close as possible to the hub and try again--you can move to your final location when completed.

Note: If the manual button doesn't light up after pressed 3 times, please reset the device: click the button 2 times quickly then hold for at least 10 seconds. This operation could be done when manual control is functional--single press can turn on/off the lamp.

To Remove The Device

- 1. Follow the instructions for your Z-Wave certified controller to remove a device from the Z-Wave network
- 2. Once the controller is ready to remove your device, press the manual/program button on the smart plug 3 times quickly.

To Return The Device To Factory Defaults:

Manual: Click the button 2 times quickly then hold for at least 10 seconds. Host reset: Remove it from hub the device will factory reset.

(LED flashes 2 times when the configuration parameter changed.) Support 2 groups, each group max support 2 devices

> Group 1 lifeline Group 2 Left outlet send basic set

★ Please contact us if you have any questions:

ask@minoston.com www.minoston.com



Parameter Settings

LED Indicator

This parameter can access you to choose the led indicator to be on when the plug(light) is on/off, or LED indicator remains on/off all times.

Operation: quickly press 6 times to change this parameter .

(LED flashes 2 times when the configuration parameter changed.) Parameter =1, size =1byte,

Value=0(Default) Load On, LED Indicator On Value=1 Load On, LED Indicator Off Value=2 LED Indicator always Off

Auto Turn-Off Timer

This parameter can access you to set a timer to make the switch turn off automatically after the switch turned on. The number entered as value corresponds to number of minutes.

Operation: Set up on the hub.

(LED flashes 2 times when the configuration parameter changed.)

Parameter = 2, Size=4, Value: 0-65535(minutes);

Value=0(default) turn off the outlet

Auto Turn-On Timer

This parameter can access you to set a timer to make the switch turn on automatically after the switch turned off. The numberentered as value corresponds to number of

Operation: Set up on the hub.

(LED flashes 2 times when the configuration parameter changed.) Parameter =4, Size=4, Value: 0-65535 (minutes);

Value=0(default) turn on the outlet

Restores state after power failure

This parameter can access you to set the switch to be on/off after power failure.

Operation: quickly press 10 times to change this parameter. (LED flashes 2 times when the configuration parameter changed.)

 $Parameter \!\!=\!\! 6, \; Size \!\!=\!\! 1,$

Value=0 output off Value=1 output on

Value=2 out put the state after power(default)

Generic Device Class:

0x10 - GENERIC_TYPE_SWITCH_BINARY

Specific Device Class:

0x01 - SPECIFIC_TYPE_POWER_SWITCH_BINARY

Command Classes:

0x5E - COMMAND_CLASS_ZWAVEPLUS_INFO

0x86 - COMMAND_CLASS_VERSION

0x72 - COMMAND_CLASS_MANUFACTURER_SPECIFIC 0x5A - COMMAND_CLASS_DEVICE_RESET_LOCALLY

0x85 - COMMAND_CLASS_ASSOCIATION 0x59 - COMMAND_CLASS_ASSOCIATION_GRP_INFO

0x73 - COMMAND_CLASS_POWERLEVEL 0x25 - COMMAND_CLASS_SWITCH_BINARY

0x27 - COMMAND_CLASS_SWITCH_ALL

0x70 - COMMAND_CLASS_CONFIGURATION

0x8E - COMMAND_CLASS_MULTI_CHANNEL_ASSOCIATION

0x55 - COMMAND_CLASS_TRANSPORT_SERVICE 0x9F - COMMAND_CLASS_SECURITY_2

0x6C - COMMAND_CLASS_SUPERVISION

0x7A - COMMAND_CLASS_FIRMWARE_UPDATE_MD

Warranty

Our Products warrants this product to be free from manufacturing defects for a period of one year from the original date of consumer purchase. This warranty is limited to the repair or replacement of this product only and does not extend to consequential or incidental damage to other products that may be used with this product. This warranty is in lieu of all other warranties, expressed or implied. Some states do not allow limitations on how long an implied warranty lasts or permit the exclusion or limitation of incidental or consequential damage, so the above limitations may not apply to you. This warranty gives you specific rights, and you may also have other rights which vary from state to state.

This device complies with part 15 of the FCC and Industry Canada license-exempt RSS standard(s). Operation is subjected to the following two conditions:
(1) this device may not cause harmful interference, and (2) this device must accept any interference received,

including interference that may cause undesired operation

FCC NOTE: The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. Such modifications could void the user's authority to operate the equipment.

— Reorient or relocate the receiving antenna.

Increase the separation between the equipment and receiver.

Consult the dealer or an experienced radio/TV technician for help.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following

Important note: To comply with the FCC RF exposure compliance requirements, no change to the antenna or the device is permitted. Any change to the antenna or the device could result in the device exceeding the RI exposure requirements and void user's authority to operate the device.

CAUTION - PLEASE READ!

This device is intended for installation in accordance with the National Electric Code and local regulations in the United States, or the Canadian Electrical Code and local regulations in Canada. If you are unsure or uncomfortable about performing this installation consult a qualified electrician.

WARNING

RISK OF FIRE RISK OF ELECTRICAL SHOCK

TO REDUCE THE RISK OF ELECTRIC SHOCK, THIS PRODUCT HAS A GROUNDING TYPE PLUG THAT HAS A THIRD (GROUNDING) PIN. THIS PLUG WILL ONLY FIT INTO A GROUNDING TYPE POWER OUTLET. IF THE PLUG DOES NOT FIT INTO THE OUTLET, CONTACT A QUALIFIED ELECTRICIAN TO INSTALL THE PROPER OUTLET. DO NOT CHANGE THE PLUG IN ANY WAY.

CONTROLLING APPLIANCES: CAUTION: TO REDUCE THE RISK OF

OVERHEATING AND POSSIBLE DAMAGE TO OTHER EQUIPMENT

• DO NOT EXCEED RATINGS

• DO NOT USE TO CONTROL ANY DEVICE WHERE UNINTENDED OPERATION COULD

CAUSE UNSAFE CONDITIONS (HEAT LAMP, SUN LAMP, ETC.)

MEDICAL EQUIPMENT

Please DO NOT use this switch to control Medical or Life Support equipment. Z-Wave devices should never be used to control the On/Off status of Medical and/or Life Support equipment

CONTROLLING APPLIANCES

Please exercise EXTREME CAUTION when using Z-Wave devices to control appliances. Reason being is because the appliance you want to control may be in a separate room and if unintentional behavior occurs (such as adevice turning on or off - either intentionally via schedules, or unintentionally via network error) this event may lead to a hazardous condition. For these reasons, please note the following suggestions:

1) Do not include Z-Wave devices in Groups or Scenes if they control appliances 2) Do not use Z-Wave devices to control electric heaters or any other appliances which may present a hazardous condition due to unattended, unintentional, or automatic power control.