EN   Get started with your Idem tag reader

1. Charge reader via USB.

2. Download Idem app in **App Store** or **Google Play**.

3. Press button on reader and release to turn on reader until it flashes blue.

4. By using Bluetooth®, connect reader via Connect button in Idem app until reader flashes white.

5. Mount Idem tags on CNC tools
   Note: Tags supplied separately.

6. Scan mounted tags with reader to configure empty tags or scan already configured tags, until reader starts to glow green. *Note: RFID technology requires minimal distance between reader and tags.*

7. Follow further instructions in Idem app for all features.

Idem system support idemtools.com/ email contact@idemtools.com