


USER MANUAL

CL-240



MADE IN CHINA

FCC Caution:

This device complies with part 15 of the FCC Rules.

Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

To maintain compliance with FCC's RF Exposure guidelines, This equipment should be installed and operated with minimum distance between 20cm the radiator your body: Use only the supplied antenna.

1. Important information

**PLEASE READ THE INSTRUCTIONS CAREFULLY BEFORE USING
KEEP INSTRUCTIONS FOR FUTURE REFERENCE**

IMPORTANT SAFETY INSTRUCTION


Before operating, please read instructions carefully.

1. Clean only with a dry cloth. Disconnect power cord from outlet bear cleaning.
2. Only use original power cord supplied with the product.
3. Do not place near heat sources including radiators, ovens, etc.
4. Do not use if power cord or product has been damaged.
5. Do not make any modifications to product.
6. Carefully arrange power cord so it can not be tripped over or pulled by children.
7. Do not overcharge the battery, the standard charging time is a maximum of 12 hrs, overcharging may shorten the battery life.
8. Do not immerse the cooler in water when cleaning, electronic parts will get damaged.
9. When use it can be placed on the ground or on the table.

2. Package



product unit




charger unit



Manual




Cigarette Lighter Cable



Adapter


3. Interface Description

View1



- 1) Power : Power ON/OFF (Long press for 3 seconds).
- 2) FAN A: Short press to adjust FAN A blowing rate.
- 3) FAN B: Short press to adjust FAN B blowing rate.
- 4) Bluetooth Speaker Power : Bluetooth Speaker ON/OFF (Long press for 3 seconds).
- 5) Charge Light: Red light indicates that unit is charging
Blue light indicates that unit is fully.

View1




- 6) Battery level Light:Red light indicates that battery is empty white light indicates that battery is fully.
- 7) Fan level Light:one light indicates that fan is low,three lights indicates that fan is fast.
- 8) Bump: Bump ON/OFF(Short press).
- 9) Charge Input Port: DC12V 10A.
- 10) Output Port: DC5V 1A(Max).

Charging instructions:

DC Port/ Charger Charging	Insert power cord to charge.
	Red light indicates that unit is charging.
	Blue light turn on when fully charged.
	Do not charge more than 12 hours even if red light stays.
	Unplug power cord once charging is complete.

4. BT Mode Operation

- 1) Turn on the power, the product enters BT status automatically.
- 2) Enter Bluetooth Pairing Mode on your device. Select ' CL-240 ' from the device list. The speaker will audibly ping once Bluetooth connection has been successful.The Speaker will then be stored in your Bluetooth 'Device List' for future pairing.



5. Specification

Function	Specification
Input	DC12V 10A(Max)
Output	DC5V 1A(Max)
Adapter	DC12V 10A
Battery	10.8V 10400mAh
Charger Input	DC12V 3.5A(Max)
Bluetooth Version	5.0
Bluetooth Distance	6.0M at Max
Frequency Range	2.4GHz-2.48GHz
RMS	5W+5W
Driver Impedance	4Ω
Frequency Response	90Hz-20KHz
Environment Temperature	0℃~40℃