# Pow Mo Manual

# **Technical Parameters:**

Built-in battery supply voltage: 3.7V

Speaker: 2-channel stereo, 2\*4.5W

Charging voltage: DC 5V

# **Functional Overview:**

- 1、Bluetooth version 4.2
- 2、After 30 minutes of no sound playback, the auto power off function.

# 3、TWS function

# **Button definition:**

2 buttons:

Power button:

(1) Power button: long press to turn on/off

(2) The machine restarts after resetting for 8 seconds (reset): This function can only be used if the audio crashes and the system cannot be turned off.

Bluetooth button:

(1) Short press to enter Bluetooth pairing.

(2) Long press to enter TWS pairing. After the pairing connection is successful, press and hold again to disconnect the TWS connection.

## LED lights show:

Blue: Bluetooth status; Green: TWS status; Red: Charging status.

# Single Speaker Use:

## **Bluetooth connection:**

After long press the power button to turn on, the LED light is displayed as blue light; short press the Bluetooth button, the machine enters the pairing state, the blue light becomes slow flashing and the pairing prompt sounds. The external Bluetooth device (such as a mobile phone) searches for the audio

Bluetooth name via Bluetooth and successfully connects with it. After the connection is successful, the

blue light is on and you can start playing music.

#### **Disconnect the Bluetooth connection:**

In the case that the audio is connected to the external Bluetooth device, short press the Bluetooth button to disconnect the audio from the current Bluetooth device (such as a mobile phone), and at the same time enter the pairing, waiting for other devices to be paired with the audio.

## TWS function uses:

## TWS pairing connection:

(1) The mobile phone is successfully paired with the host computer according to the single-machine usage method.

(2) The host computer long presses the Bluetooth button, the LED light shows green slow flashing, indicating that the station sends a TWS pairing command and simultaneously issues a TWS pairing tone. Another slave audio, short press the Bluetooth button to enter the pairing, waiting for the host to pair with the TWS.

(3) When the TWS pairing is successful, the two audio LED lights are all green and bright. The host is the L channel and the slave is the R channel.

#### **TWS disconnected:**

In the case of a TWS connection, long press the Bluetooth button to disconnect the TWS.

Note: If the TWS connection is successful, it will be shut down. If you want to enter the TWS function after re-booting, you need to re-do the TWS pairing connection again.

## charging:

The TPYE-C interface is used for DC 5V charging. When the USB interface is plugged in, the indicator light is red, indicating that it is charging. When fully charged, the red light goes out.

#### Automatic shutdown power saving function:

In order to save power, the sound will automatically shut down when the sound is detected and no sound is transmitted for 30 minutes.

#### **FCC Statement**

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

-Reorient or relocate the receiving antenna.

-Increase the separation between the equipment and receiver.

-Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

-Consult the dealer or an experienced radio/TV technician for help.

To assure continued compliance, any changes or modifications not expressly approved by the party.

Responsible for compliance could void the user's authority to operate this equipment. (Example- use only shielded interface cables when connecting to computer or peripheral devices).

This equipment complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and

(2) This device must accept any interference received, including interference that may cause undesired operation.

RF warning statement:

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.