

Box PCs

ABPC-4200

System

OS	Android 9 (optional Linux)
CPU	Dual Core Cortex A72 with Quad Core A53
GPU	MALI T860MP4
System Memory	4GB DRAM
Internal Storage	16GB eMMC
Network LAN RJ45	10/100/1000 Mbps LAN
WiFi	802.11 a/b/g/n/ac 2.4&5GHz
Bluetooth	BT 4.2

Video/Audio

Media Support	DIVX, H.264/AVC, H.265/HEVC, MPEG-1/2, MPEG-4, MVC, GOOGLE VP8/VP9, H.263, VC-1, MOTION JPEG, Audio MP3, WMA, WAV, AAC, OGG, FLAC, Picture JPEG, BMP, GIF, PNG, WEBP
----------------------	--

Physical

Housing	Metal
Color	Black
Weight	470 g
Dimensions	153 x 107 x 31 mm
Mounting / VESA	VESA 75/100 x 120 mm
Power Supply	12V / 2A DC input
Power Usage	10 ~ 15 Watt

Other

I/O Ports	USB 3.0,USB 2.0,3.5 mm (IR and PIR sensor in),GPIO Port,3.5 mm audio-out,RJ45,Combo Jack,HDMI-out 2.0,HDMI-in 1.4,USB-C,RS232 (2x)
Microphone	YES
Audio Jack Output 3.5	YES
Standard Warranty	3 years



Box PCs

ABPC-4200

This device complies with Part 15 of the FCC Rules.

Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

Box PCs

ABPC-4200

NOTE:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC rules.

These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

FCC RF Radiation Exposure Statement:

1. This Transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.
2. This equipment complies with FCC RF radiation exposure limits set forth for an uncontrolled environment.

This equipment should be installed and operated with a minimum distance of 20 centimeters between the radiator and your body.