




Function Display



安装流程

Installation Process



新增设备 Add AquaSensor Device Process

1 27°C 6 87%

Search for near AquaSensor Device



查看信息


Check Plant Data




如何浇水 Watering Process

Reminder Touch AquaSensor Screen

提示触摸蓝牙标签







Finish and Move to Next Plant

继续触摸下一盆






Touch and Start AquaSensor 触摸蓝牙标签

Record Watering Data

记录浇水信息








Display Current Data and Watering Reminder



指示灯说明

Indicator Light Illustration



常见问题

01 为什么提示检测期?

我们基础功能是查看当前水位、温度、土壤湿度,我们还可通过24小时的记录水位变化预测您植物何时耗干并需要浇水,但是需要一段时间检测才能完成,这段时间就是检测期,您按相关提示操作即可。

02 新增为什么要选择盆器类型?

盆器两种情况,如果是购买我们的盆器,您选择对应的盆器后,可获取盆器的容水量,更快的完成检测期。如果您是自己的盆器,未设置盆器使用蓝牙标签的后水位对应的容量,检测期可能会更长。

03 怎么更换电池?

我们使用的是3A电池,您可使用螺丝刀将后盖螺丝捏下,更换对应规格电池。

04 手机号收不到验证码怎么办?

目前我们仅支持中国地区手机号注册。如您账号上有疑问可发送电邮至 3507453815@qq.com

05 电池可以消耗多久?

我们原装配送是国际标准的3A电池, 且未激活状态下功耗很低, 再激活后正常情况下使用可保证使用半年以上。

06 如何设置浇水量及标准水位

浇水的量是根据标准水位计算。如需设置可在浇水时,在设备点击 连接后,进行设置。

FAQ

01 Why there is detection period?

Our basic function is check plant current water volume, temperature and soil humidity. We can predict your plant's water consumption and remind when you need to watering through 24 hours water level change record. It's completed by a period of detection time. It's easy to handle according to relevant tips.

02 Why need to choose planter type when add device.

There are two forms of planter. For purchase from us, you just need to choose matching planter then get the water volume, it saves time to finish detection period. For using your own planter, it needs more time to set up device and make detection.

03 How to replace the battery?

AquaSensor uses 3A battery, you can replace the matching battery by opening rear cover with screwdriver.

04 What should I do if my mobile phone dosen't receive a verification code?

We support China phone number to receive a verification code for App register at present. For other countries, an email verification code is available.

05 How long would the battery use?

International standard 3A battery is our original one. It consumes less before activation and use for half a year after activation. Battery lifespan is improving soon that will last for more than six month.

Of How to set up the watering volume and standard water level?

Watering volume setup is based on standard water level. For setting up just to connect device while watering.

FCC Caution:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- -Reorient or relocate the receiving antenna.
- -Increase the separation between the equipment and receiver.
- -Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- -Consult the dealer or an experienced radio/TV technician for help.