


ARIA


xFlyro

USER MANUAL



xFlyro ARIA

Caution:
Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.




SETUP


Quick Setup

Step #1 Open charging case


Step #2 Remove earbuds from charging case



Step #3 Initially, earbuds will both slowly flash blue. Wait for one earbud to quickly flash blue and red




Step #4 Place your device in discovery mode and connect to "xFlyro ARIA"




Find our setup video by searching "xFlyro ARIA setup video" on YouTube for setup instructions!

PACKAGE CONTENTS



- 1 xFlyro ARIA Earbuds (L/R)
- 2 Charging Case
- 3 Micro USB Cable
- 4 Wingtips (3 sets, S/M/L)
- 5 Eartips (3 sets, S/M/L)


DEVICE LAYOUT




1 Earbud Button	5 Charging Case On/Off Switch
2 Indicator Light	6 Charging Case Power Level Indicator
3 Microphone	7 Charging Case Charging Contact
4 Charging contacts	8 Micro USB charging port

WEARING YOUR EARBUDS


Step #1 Identify orientation of earbud - check for L for left ear, R for right ear printed on earbud. Position earbud in your ears with wingtips facing upwards.



Step #2 While pressing earbuds further into ear canal, rotate earbuds back and forth so wingtip is placed underneath a fold in your upper ear. The wing should be tucked underneath this fold and should not be exposed.




Step #3 If done correctly, the earbud should fit snugly in your ear with the wingtips applying gentle pressure against the fold in the upper ear to secure your earbuds in place.




CHARGING YOUR EARBUDS

Step #1 Place earbuds in charging case as shown




Step #2 Press Charging Case On/Off Switch. Switch should be depressed for charging case to charge earbuds.




Note: While charging, the earbud indicator light should turn red. When the earbud is fully charged the indicator light will automatically turn off.

USING YOUR CHARGING CASE

Step #1 When switch is depressed, the charging case will actively charge if earbuds are placed in charging case.




Step #2 When switch is raised, the charging case will not charge earbuds even if earbuds are placed in charging case.




Note: To maximize charging case battery life, it is recommended to turn off charging case unless it is actively charging.

PAIRING YOUR EARBUDS MANUALLY


Step #1 Press earbud button of BOTH earbuds for 2 sec to turn on earbuds.



Step #2 Wait approximately 10 seconds for earbuds to pair with one another automatically. Pairing is successful when one earbud quickly flashes red and blue and the other earbud slowly flashes blue.




Step #3 Connect to "xFlyro ARIA" on your Bluetooth enabled device.




USING ONLY ONE EARBUD

The ARIA should come with one "Primary" earbud - by default this will be your "R" earbud. You can double check this by turning on your earbuds without pairing to a device to see which earbud flashes red and blue - this is your "Primary" earbud. The other earbud that pairs to the Primary earbud, your "Secondary" earbud, will slowly flash blue.




To use only one earbud:


Step #1 Turn OFF both earbuds




Step #2 Turn ON ONLY the Secondary earbud without turning on the Primary earbud



Step #3 Place your device in discovery mode and connect to "xFlyro ARIA"



USING ARIA'S BUTTONS



	Single Tap
	Double Tap
	Press and Hold (2 sec.)

Music Controls:

	Skip to previous track: Hold L button
	Skip to next track: Hold R button
	Lower volume: Click L button
	Increase volume: Click R button
	Double click L button to activate Siri or Google Assistant
	Pause: Double click R button
	Play: Click either L or R while paused

Calling Controls:

	Pick up call: Tap L or R button
	End call: Hold L or R button
	Rejecting call: Hold L or R button

Note: Two-Call handling is not supported on all devices.

If another call comes while you are on another call:

	1. Press and hold R button to end the current call and answer the incoming call.
	2. Tap R earbud to hold the current call and answer the incoming call.
	3. After accepting incoming call, tap R earbud to switch between calls.
	4. Hold and press R earbud to end either call.

WARNINGS

- ⚠ Carefully clean and dry the contact points on your earbuds with a soft cloth. Residue from sweat, water, or other contaminants may damage or corrode internal components.
- ⚠ Connecting the charger improperly may cause serious damage to the charging case. Any damage caused by misuse is not covered by the warranty.
- ⚠ Charging case does not have any level of water resistance and should not ever come into contact with water. Any water damage is not covered by the warranty.
- ⚠ Earbuds are rated to be waterproof for immersion of up to 1 meter up to 30 minutes in gentle waters. Salty, overly chlorinated, or contaminated water may permanently damage contacts and cause wear and tear not covered by the warranty. Exposing earbuds to high pressure water scenarios (rapid swimming, ocean waves, etc.) may permanently damage earbuds and void warranty.
- ⚠ Charging case and earbuds contain lithium ion batteries. Please follow local laws and regulations regarding proper disposal of such materials. Do not dispose into fire or water.
- ⚠ Do not force open charging case or earbuds in any way, as it may permanently damage headset, cause bodily harm, and void all warranty.

FAQ

Why are my earbuds not turning on?

- The battery may be completely discharged. Charge the earbuds battery completely before using the earbuds.
- Ensure your charging case has battery by checking the power indicator lights on the charging case. Ensure your charging case is turned on and power button is depressed.
- Ensure your device is properly paired with the ARIA - the ARIA should not be flashing red and blue (that means it's in pairing mode) and should be marked as "connected" on your device.

How do I make my earbuds fit better?

- Ensure you are properly positioning the earbuds in your ears as instructed on Page 6 - the wingtips should be facing upward and underneath your ear flap exerting a gentle pressure to keep a snug fit. Wingtips should NOT be visible if inserted properly.
- You may not be using the best size wingtip or eartip. Swap your current wingtip or eartip with one of the other included sizes.

How can I achieve optimal sound performance?

- Optimal sound performance naturally occurs after the "burn-in" or "breaking-in" period of 200 hours of listening. Keep using your ARIA to reach the greatest listening experience possible.

Why are my earbuds not charging?

- Ensure your charging case is on - the Charging Case On/Off Switch should be depressed.
- Ensure your charging case has power and that your earbuds are charging - the indicator lights on your earbuds should be on if they are charging.

FAQ

• Clean the contact points on the earbuds to make sure no dirt is blocking the contact. Adjust the silicon wrapper around the earbuds to make sure that it is not blocking the contact.

Why do my earbuds keep pairing to my device / phone even while it's in the charging case?

- Your charging case has run out of battery, and the earbuds have turned on and paired to your phone thinking it has been removed from the charging case without an active electric charge.
- Turn off your earbuds manually and do not place back into charging port until you recharge your charging case.

How do I connect to another device?

- Turn off Bluetooth discovery on all devices except your target device and repeat the Quick Setup instructions using new target device. Note this may reset this new device as priority for auto-pair.

Why does my earbuds' battery life seem short?

- Earbuds battery life can drain faster based on temperature, sound volume, distance from paired device, interference from other Wi-Fi and Bluetooth sources, and many other factors.
- Tips on maximizing battery life
 - ✓ Lower playing / calling volume;
 - ✓ Keep earbuds close to paired device;
 - ✓ Avoid storing your earbuds at extreme temperatures (cold or hot);
 - ✓ Keep earbuds away from interfering signals.

FAQ

Why are my earbuds and/or charging case heating up?

- While charging, the earbuds and the charging case may heat up. This is normal and should not affect the earbuds' lifespan or performance.
- Earbuds may get warm while playing due to an accumulation of body heat or extended earbud battery use (e.g. volume is too high, connectivity with paired device is poor, etc.). This is normal and should not affect the earbuds' lifespan or performance.

How do I know the earbuds are done charging?

- Your earbuds can take up to 2 hours to fully charge. Once earbuds are done charging, the red light on the earbuds will turn blue for 120 seconds, after which, the indicator light will turn off. Once you do not see the indicator light on (red or blue), they should be done charging.

How far away can I be from my device while using ARIA?

- The xFlyro ARIA can operate up to 10m (33 feet) away from your connected device. However, if there are many layers of walls and objects between your device and the earbuds, the Bluetooth range will decrease.

How waterproof and dustproof are my earbuds?

- The xFlyro ARIA is certified with an IP67 rating, which means that it is fully protected from dust (6) and can also withstand being submerged in 1m (about 3.3 feet) of static water for up to 30 mins (7).

Can I use the earbuds individually?

- Yes - see instructions on Page 10

FAQ

How do I connect to another Bluetooth-enabled device, including a TV? Can I use the earbuds with multiple devices?

- Turn off Bluetooth discovery on all devices except your target device and repeat the Quick Setup instructions using new target device. Note this may reset this new device as priority for auto-pair.
- You can connect multiple devices to your earbuds by following the above instruction.

How fast does the charging case recharge the earbuds?

- Your earbuds should be charged within 2 hours if the charging case has sufficient charge.

Can I use different earbud tips with this unit (are they universally compatible)?

- The eartips are compatible with many industry fittings, but depending on the eartip and wingtip it may interfere with the fitted charging port.

How do I know when the charging case is finished charging?

- The charging case's power level indicator will be fully lit up.

How many times can the charging case charge my earbuds?

- The charging case can charge your earbuds to full up to 4 times.
- The charging case's power level indicator will be fully lit up.

DISCLAIMER

- The items supplied with the earbuds and any available accessories may vary depending on the region or service provider.
- The supplied items are designed only for xFlyro ARIA earbuds and may not be compatible with other devices.
- Appearance and specifications are subject to change without prior notice.
- You can purchase additional accessories from the xFlyro website. Make sure they are compatible with the earbuds before purchase.
- Use only xFlyro accessories. Using unapproved accessories may cause performance problems and malfunctions that are not covered by the warranty.
- Availability of all accessories is subject to change depending entirely on manufacturing companies. For more information about available accessories, refer to the xFlyro website.

WARRANTY INFORMATION

Our company provides a 90 (ninety) day limited warranty guarantee. If you have any problems during this time, please contact your vendor. This Warranty does not apply to (a) consumable parts such as batteries or protective coatings that are designed to diminish over time, unless failure has occurred due to a defect in materials or workmanship; (b) to cosmetic damage including but not limited to scratches, dents and broken plastic on parts unless failure has occurred due to a defect in materials or workmanship; (c) to damage caused by use with a third party component or product outside of package contents; (d) to damage caused by accident, abuse, misuse, fire, liquid contact, earthquake or other external cause; (e) to damage caused by operating the Product outside xFlyro's published guidelines; (f) to damage caused by service (including upgrades and expansions) performed by anyone who is not a representative of xFlyro; (g) to a Product that has been modified to alter functionality or capability.

WARRANTY INFORMATION

without the written permission of xFlyro, (h) to defects caused by normal wear and tear or otherwise due to the normal aging of the Product; (i) if any serial number has been removed or defaced from the Product; or (j) if xFlyro receives information from relevant public authorities that the product has been stolen or if you are unable to deactivate passcode-enabled or other security measures designed to prevent unauthorized access to the Product, and you cannot prove in any way that you are the authorized user of the product (e.g. by presenting proof of purchase).

Please visit the official xFlyro website at www.xflyro.com to register your product within 30 days of purchase to be eligible for the warranty!

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications; however, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.


Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference;
- (2) this device must accept any interference received, including interference that may cause undesired operation.

FAQ

Disassembling or altering any part of this product may void the warranty.



CE FC RoHS



Designed in USA
Assembled in China

xFlyro - Audio Reimagined
E-mail: Hello@xflyro.com
Website: www.xflyro.com

