

User manual

Product Name: Bluetooth Headphones

Trade Name: dyplay

Model Name: ANC 30

Series Model: ANC 40, ANC 45, ANC X, ANC Free

Manufacture's Name: Beijing Qunlitiancheng Network
Technology Co., Ltd.

Frequency: 2402 – 2480 MHz

ANC 30

Active Noise Cancelling Bluetooth Headphones

Please read this instructions carefully and keep them


Pairing your Mobile Device

1. Press and hold the power button 2–4s until the Bluetooth indicator blinks blue.
 2. On your mobile device, turn on the Bluetooth feature.
- Tip: The Bluetooth feature is usually found in the Settings menu.
3. Select your display ANC 30 wireless headphones from the device list.
 4. Play music on the connected mobile device.

Starting Up Automatically Reconnection

Press and hold the power button for 2–4 seconds to start the headphones and the headphones will automatically reconnect a recently connected device. If you want to connect another device, press and hold the power button to disconnect the first device.

Function Key Introduction



PS:1. It is not allowed to be used when charging, and the power will be off automatically when charging. Depend on the function of the phone, there may be differences in the way of operating.

2. The noise cancelling function can be used even the headphones is turned off. The noise cancelling function is powered by the battery in the headphones. So it is suggested to turn off the noise cancelling function to avoid the power loss when the noise reduction function is not used.

FCC Caution.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.