





eWBM Co., Ltd. www.e-wbm.com

Seoul, Republic of Korea

e-mail:support@e-wbm.com







Specifications

Model	eFA450
FIDO	FIDO1.1 FIDO2
USB TYPE	USB Type A
SIZE	53.1x17x7mm
WEIGHT	6.6g
COLOR	White Black
OS	Windows 10, Mac Support

eWBM GOLDEN GATE











www.e-wbm.com

GOLDEN GATE eFA450













User's Guide Preview Details (English Version-eFA450)

- *This product uses DC 5V
 - You must register your fingerprint before using the eFA450



[1] eFA450 USB is recognized



[2] Register your fingerprint with the eFA450 USB



[3] After 1st authentication with ID/PW, log in by executing 2nd authentication with eFA450

Fingerprint Registration Manual





After the eWBM Golden Gate screen appears, click 'Register a thumbprint'.



Type a name and click Register Fingerprint. (Enter in Korean 10 characters and in English 10 characters.)



When the fingerprint registration window appears, register the fingerprint with the eWBM Golden Gate. (Repeat 5 times)



When the word 'fingerprint was successfully registered' appears, it was registered normally in the eWBM Golden Gate.

FCC Warning Statements

FCC Part 15.19 Statements:

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

FCC Part 15, 105 statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC Part 15.21 statement

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.