

NUARL®


Bluetooth Headset N6 Sports




完全ワイヤレスイヤホン N6 Sports シリーズ ユーザーズガイド

Operation Manual/ 操作説明書

Product Diagram



※Please choose and replace Ear Tip to suit your preference.



Before Use

■ Remove Insulating Sheet

Remove Insulating sheet from back side of earbuds.





■ Battery Charge

Insert USB type A connector of USB Charge Cable to USB AC charger or USB port of PC, and insert Type C USB connector to USB port of Charging Case.

Put the Ear Buds into Charging case .

While charging, the LED light constantly.

When charging is completed, the LED will turn off.



■ Power On/Power Off

Put the Ear Buds into Charging Case , Ear Buds power OFF automatically.

When pick up the Ear buds, power ON automatically.

※When Case battery is low, this function does not work.

Pairing

■ Pairing


To use Ear Buds first time, you must pairing Ear Bud with mobile phone or player. Once your Ear Buds is paired with other devices, they will remain paired and automatically recognize each other.

【First time to use】

1. Turn on Bluetooth function of your mobile phone.
2. Turn on the power of both earbuds.
3. Select "NUARL N6 Sports" in discovered device list of the phone.
4. Click "Pair" in the phone display.

【Re-pairing or Pairing with second mobile phone】


1. Turn on Bluetooth function of your mobile phone.
2. When Earbuds is not connected to any other device, the LED indicator will blink alternately in white and orange after 6 seconds.
3. Select "NUARL N6 Sports" in discovered device list of the phone.
4. Click "Pair" in the phone display.



Charging Case

■ Charge Case Battery

Insert USB type A connector of USB Charge Cable to USB AC charger or USB port of PC, and insert Micro USB connector to USB port of Charging Case. Depending of battery level, the number of lit LED will change.



■ Auto Power ON/OFF

Put the Ear Buds into Charging Case, Ear Buds power OFF automatically. When pick up the Ear buds power ON automatically.
※When Case battery is low, this function does not work.

Ambient Mode

This device is equipped with an Ambient mode that allows you to listen to ambient sounds from the microphone.

When the wind hits the earphones with the Ambient mode enabled, a wind noise can be heard. This is not a product defect.

Gaming Mode

By enabling the gaming mode, you can reduce the audio delay in relation to the video.

However, sound quality and Bluetooth stability may be degraded while in the gaming mode.

Meaning of LED

Power ON	White 1 Second
Charging	Orange
Disconnected	White 2time each 3Seconds
Connected	White 1 time each 7Seconds
Music Play/Talking	No Flash
Low Battery	Orange 1 time each 3Seconds
Pairing	Flashing White and Orange

Button Operation

		L	R
Power	ON	Long press 2 seconds	Long press 2 seconds
Music	Play/Pause	1 Click	
	Next Track	-	Long press 1 second
	Previous Track	Long press 1 second	-
Volume	Volume Up	2Click	-
	Volume Down	-	2Click
Phone	Answer Call	1 Click	
	Hang Up	1 Click	
	Reject Call	Long press 2 seconds	
Ambient Mode	ON/OFF	-	Long Press 1 sec without Music play
Gaming Mode	ON/OFF	3Click	
Siri/GA	Start	Long Press 1 sec without Music play	-

Frequently Asked Questions

Q) Suddenly I heard no sound from one earbud.

A) Please turn off earbud and turn on it again.

Q) The white LED lamp of the earphone is continuous blinking.

A) With the earphones on the side that is **not blinking continuously white, press and hold for about 10 seconds, then double tap. When the continuous white flashing of both earbuds stops, try pairing them with phone again.**

Q) Bluetooth connection has dropped.

A) Please delete 「NUARL N6 Sports」 from Bluetooth device list and pairing with your device again.

Q) The pairing between L and R earbud has dropped.

A) Turn off both earbuds and turn on them again.

Q) When I place the earbud in the case, it won't turn off itself.

When I get the earbud out from the case it won't turn on.

A) While the case's power is low, the automatic on off function will not be active. Please turn on/off it manually.

Q) The case has run out of charges.

A) The case will discharge itself, please recharge the case regularly.

Q) I want to know about warranty and repair in outside of Japan.

A) The warranty for this product is valid for 1 years from the day of purchase. During the warranty period, we will repair the product . The warranty is only valid in the country in which the product was purchased. Please contact purchased store directly for the specific repair of the goods.

Specification

Product Specification	
Driver	Φ6mm PTT Diaphragm NUARL DRIVER[N6]V3
Frequency Response	20~20,000Hz
Power	Earbuds: 3.7V/55mAh Li-Po Battery Charger Case: 3.7v/4800mAh Li-Po Battery
Continuous Play time (Max)	10hours(SBC/AAC) / 7hours(aptX)
Total Play time (Max)	60hours(with Charger Case)
Charging Time (Min)	1.5hours
Bluetooth Specification	Version5.2/Class2/Multi-Pairing(4)
Bluetooth Codec	aptX Adaptive, aptX, AAC, SBC
Bluetooth Profile	A2DP, HFP, AVRCP
Bluetooth Passkey	0000
Microphone	cVc NC/Ambient sound combined use
Waterproof Level	IPX7
Operation Temperature	5~50°C
Accessories	Block Ear + (4size), Track Ear+ (3size), Charger Case, Charging Cable, User's Guide
Certification	R210-44986(JP)

FCC Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.