

User Manual

Manual for vehicle manufacturer

Product name: SMART CARD KEY

OUTLINE

1. How to use SMART CARD KEY

- SMART CARD KEY is a part of Remote Keyless System.
- This unit controls door lock/door unlock/trunk open/panic/remote engine start-stop/forward/backward wirelessly.

2. Introduction of Transmitter (SMART CARD KEY)

- These units use the battery
- Frequency is 433.92MHz, 6.5GHz

GENERAL DESCRIPTION

PRIMARY FUNCTION

- Remote door lock/door unlock/trunk open/panic/remote engine start-stop/forward/backward
- Operating voltage: 3V DC
- Center freq.: 433.92MHz

UWB FUNCTION

- UWB signal is used to enhance vehicle security and it operates automatically under necessary conditions regardless of the user's specificaction of pressing any buttons.

MANUAL

1. LOCK Button

If the LOCK button is pressed, then TRANSMITTER sends the LOCK data.

2. UNLOCK Button

If the UNLOCK button is pressed, then TRANSMITTER sends the UNLOCK data.

3. TRUNK Button

If the TRUNK button is pressed, then TRANSMITTER sends TRUNK open data.

4. PANIC Button

If the PANIC button is pressed, then TRANSMITTER sends PANIC data.

5. Remote Engine Start-Stop Button

If the Remote Engine Start-Stop Button is pressed, then TRANSMITTER sends the Remote Engine Start-Stop data.

6. Forward Button

If the Forward button is pressed, then TRANSMITTER sends Forward data.

7. Backward Button

If the Backward Button is pressed, then TRANSMITTER sends the Backward data.

FCC Information to User

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is con-nected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution

Modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

FCC Compliance Information: This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation