



STEALTH LONG RANGE

2.4GHz

2.4G Transmitter

USER MANUAL VERSION 1.0

Please contact us if you need further assistance:

Tech support: tech@furiousfpv.com

Sales support: sales@furiousfpv.com

Website: <http://furiousfpv.com/>



CONTENTS


Features.....	2
Pin Outs.....	2
Dimensions	3
Weight.....	3
Tips	4
Support	4

Features

- Transmission Frequency: 2.4GHz & Available Channels: 16/ 8(EU Version)
- Selectable Power: 10mW/25mW/200mW/500mW/800mW or 10mW(EU Version)
- Input Voltage: 7V - 26V (2S - 6S)
- BEC 5V@2A + LC Filter => Clean Signal
- LED Ports: (2) LED Ports for LED Strip Functionality
- On Board Display: RGBLED
- RF Connector: MMCX
- Dimensions: 38.2mm x 24.8mm x 9mm (LxWxH)
- Weight: 8.5g (antenna excluded)
- Wire & Connector: High Quality Silicon & GH Connector
- Shield: Easy to Mount Metal Protection Shield
- VTx Control: Uses Furious FPV Protocol to Control via FC (available via later firmware update and only supports Betaflight & INAV)




Pin Outs



*Note:

- + VTx Peripherals is FuriousFPV Protocol- Release soon
- + VTx Peripherals only supports Betaflight & INAV

Dimensions



Weight



Tips

Antenna recommend:

1. Furious FPV - Circular Antenna RHCP 2.4 GHz – SMA: <https://goo.gl/peFM2G>

Support

The reseller you purchased your product from handles the first line of support. If you encounter any problems with your Furious FPV products, please contact them first on issues involving equipment from other brands and general support for Furious FPV products.

Please contact us if you need further assistance:

Tech support: tech@furiousfpv.com

Sales support: sales@furiousfpv.com



Thanks for using our product

FCC WARNING

FCC Caution: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

This device complies with Part 15 of the FCC Rules.

Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This device and its antenna(s) must not be co-located or operating in conjunction with any other antenna or transmitter.

15.105 Information to the user.

(b) For a Class B digital device or peripheral, the instructions furnished the user shall include the following or similar statement, placed in a prominent location in the text of the manual:

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules.

These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20 cm between the radiator and your body.

Radiation Exposure Statement:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment.

This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

The availability of some specific channels and/or operational frequency bands are country dependent and are firmware programmed at the factory to match the intended destination.

The firmware setting is not accessible by the end user.

The final end product must be labelled in a visible area with the following:

“Contains Transmitter Module 2ARL3-VTX2G4”