



Easy Guide to Pairing the ACCU911 iBeacon to your Device

Step by Step: Android

Step 1: iBeacon must be "paired" to the Android device before they can communicate

Step 2: Go to Home, Menu, Settings, Wireless & Networks, *Bluetooth* Settings to find this feature. Select the Bluetooth box to turn on enabling. This ensures that your Android phone can communicate with iBeacon

Step 3: Next Download the ACCU911 app on your mobile device

Step 4: While the ACCU911 app is downloading you can insert the ACCU911 iBeacon plug into a powered wall Socket

Step 5: Once the application has downloaded you are ready to begin pairing your device

Step 6: Await the flash of the green indicator light on the ACCU911 iBeacon plug

Step 7: The ACCU911 app will then guide you through easy to follow prompts that enable you to register the device with ACCU911 System

Step 8: Once you have successfully gone through the registration process and the steps that your app guides you through, you will receive a confirmation email and/or text message

Step by Step: iPhone

Step 1: iBeacon must be "paired" to the iPhone device before they can communicate

Step 2: Go into Settings, General, Bluetooth, and set Bluetooth to ON. Select the Bluetooth box to turn on. This ensures that your iPhone can communicate with iBeacon

Step 3: Next Download the ACCU911 app on your mobile device

Step 4: While the ACCU911 app is downloading you can insert the ACCU911 iBeacon plug into a powered wall Socket

Step 5: Once the application has downloaded you are ready to begin pairing your device

Step 6: Await the flash of the green indicator light on the ACCU911 iBeacon plug

Step 7: The ACCU911 app will then guide you through easy to follow prompts that enable you to register the device with ACCU911 System

Step 8: Once you have successfully gone through the registration process and the steps that your app guides you through, you will receive a confirmation email and/or text message

*** Please Note – These Instructions are subject to change without notice ***

FCC WARNING

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

To maintain compliance with FCC's RF Exposure guidelines, This equipment should be installed and operated with minimum 20cm distance between the radiator your body: Use only the supplied antenna.