




Operating Manual


LUMICHARGE II

Model: HZ-X18



Thank you for purchasing your LumiCharge Smart Lamp. Please read the manual carefully and keep for later use. WWW.lumicharge.com

LED Display Operation



LED Screen Functions

- 1. Time Display**
Shows time of the day, date(Month and Day), day of the week, temperature. The timedisplay can be set for 12 or 24 hour view as well.
- 2. Alarm Clock/Event Reminder**
The alarm clock can be set so sound is played at the time that the alarm is set for. you can also set a day and time so you can be reminded of an important date like a birthday or anniversary.
- 3. Timer**
A timer can be set for as much as 24 hrs. Once the timer is done, Lumicharge will play a noise notifying the user that the time has expired.
- 4. Temperature**
Ambient temperature is displayed. When the lamp is idle, pressing the SET button on the back of the display will change the display between °C & °F readings.

Operating and Setting the LED Screen

When powering on your Lumicharge you are put into "Standby" mode. From here you will have the chance to set the time, alarm, timer, event reminder, date and day.

In Standby mode, press the Mode button to cycle through the available functions:
Standby Mode>12/24 Hour Select>Alarm Set>Event Reminder Set>Timer Set

To change the time standard between 12/24 hours, cycle through to the 12/24 Select Screen and press UP or DOWN buttons

To change the temperature reading from °C to °F, go into Standby mode and press SET button

Setting the Time

1. In Standby mode, press the MODE button 1 time. Select either 12 Hour or 24 Hour display by pushing the UP or DOWN button then push SET
2. Push UP or doWn to set the Hour then push set and set the minutes. Push Set
3. Push UP or DoWn to set the year. Push SET
4. Push UP or DoWn to set the month. Push Set and set the Day of the month. Push SET
5. When Time and Date are set, puch MODE button until you reach Standby mode

Setting the Alarm

1. In alarm mode 1, press Set key to enter alarm mode, and set hours, minutes, music in the following order. Through UP/Down to complete its settings.
Hour to minute, music to 1 to close
2. In alarm mode 2, press Set key to enter the alarm mode, and set the hours, minutes, music, alarm sounds of the corresponding week, 1 on behalf of Monday, and so on. The selected number is confirmed by Set to be completed through up/Down.
Hour to minute, music to 1234567 to close

3. If the alarm clock is turned on and the sleepiness function is not turned on, the alarm clock will ring for one minute when it reaches the set time. Press any key to stop the noise. If you are already sleepy, you can make 1 calls every 10 minutes, 1 minutes each time, 4 times.

4. When sleeping sounds, press any key to stop the noise, but the sleeping signs still flicker until the end of the four noises or cancelled.

5. when the noise is snooze, press the MODE button to stop the noise and cancel the sleepy function (that is, the sign does not show).

6. when the alarm and sleepy signs are not opened, the alarm clock and sleepiness are closed at the same time. The sleeping function can only be opened when the alarm clock signs are turned on.

7. In the setting state, if there is no button for 1 minute, the settings will automatically exit and display the current set time and date.

Setting the Timer

1. In Standby mode, push MODE 3 times. This will bring up the Timer.
2. Press SET one time and set the Hour. Press SET again to set the minutes. Press SET again to begin the Timer.

When the timer is done, an alarm will sound. To stop the alarm push the MODE button on the back of the lamp.
The timer can be set anywhere from 1 minute up to 24 hours.

Setting the Event Reminder

1. In Standby mode, push MODE 3 times. This will bring up the Event Reminder.
2. Press SET one time and set the Hour. Press SET again to set the minutes. Press SET again to set the Year. Press set again to set the Month. Press SET again to set the Day of the month.
3. Press SET one last time to set the Event Reminder. Pressing SET again will cancel the Event Remonder and the screen will display dots in place of the Hour, Minutes, and Date.

FCC Warning

This device complies with part 15 and part 18 of the FCC rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interferenceto radio or television

reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with Part 18 of the FCC Rules. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Increase the separation between the equipment and any other radio device. Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

Radiation Exposure Statement

The equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. During the operation of device a distance of 15 cm surrounding the device and 20 cm above the top surface of the device must be respected.


Key Product Features

- This product supports Wireless Charging.
- Motion Sensor Light. Lights up a dark room to make it easier to find where you are.
- High Quality LED Light Source. 3 different Hues: Soft White, White & Yellow.
- Touch Sensitive Light Adjustment. Easily select from 10 levels of intensity to fit any environment.
- Extra USB Ports. The lamp base contains 2 additional USB ports for convenience.
- Patented Charging Whell. Charge almost any device on the market with the Charging Wheel.
- Supports Apple Lightning, USB-C, and Micro USB devices.


Technical Specs

Shell Material	ABS +Aluminium + Acrylic
USB Output	DC 5V
Net Weight	946g
Product Size	7"x7"x15.8"
Color Temperature	White: 5500-6000K Soft White: 3750-4250K Yellow: 2800-3200K

Product Specs



Quick Start



Adjustment Capabilities

The Lumicharge lamp head and body can be adjusted for most situations.

Lamp Head Angle Adjustment

- The lamp head has a 195° range of motion
- When adjusting the lamp head, be sure to hold the base of the lamp for stability.

Lamp Body Forward and Backward Adjustment

- The lamp body has a forward and backward range of motion of 150°
- When adjusting the lamp body, be sure to hold the base of the lamp for stability.

Lamp Body Left to Right Adjustment

- The lamp body has a left and right range of motion of 230°
- When adjusting the lamp body, be sure to hold the base of the lamp for stability.

Warranty Card

This certificate extends the warranty for a period of 6 months from the date of purchase for Registered products. This warranty covers components and workmanship only. Replacement of Repair decision is at the discretion of the manufacturer. This certificate does not provide coverage for lost or damaged parts due to improper usage of the product. The warranty is not valid if we determine there was improper usage of the product.

Product Name
Product Color
Purchase Date

Product Registration Card

Thank You for your interest in our purchasing our product. We are happy to have you as a valued customer. Please register your product with us for future communication with us. Please send an email to lumicharge16@gmail.com to register your LumiCharge with the following details included.

Product Name/Color
Purchased From
Purchase Date
Customer Name
Contact Name or Email: