

NXGC-550 Wireless (2.4G) User Manual

Applications:

This product belongs to NXGC-550 wireless Game controller, Used for NXGC-550 Console.

Features:

1. 2.4G wireless connection, don't worry about the trouble caused by line spacing.
2. This is our private model, there will be no infringement problem.





Product operation:

NXGC-550 Console use steps: start the NXGC-550 Console, insert the Game Controller receiver into the NXGC-550 Console interface, install two dry batteries, open the Game Controller switch, and the indicator light is always on.

Wii Console use steps: Turn on the Console, first enter the game by straight handle and curved handle, then insert the NXGC-550 Controller into the Wii Console, open the curved handle, and use it on the Wii Console (Note: only support the old model Wii Console).

Precautions:

- 1) It is strictly forbidden to disassemble this product.
- 2) It is strictly forbidden to expose the product to strong light.
- 3) It is strictly forbidden to beat the product vigorously.
- 4) Do not use or store this product in high temperature or humid environment.

FCC Warning

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE 1: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

NOTE 2: Any changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.