

User Manual

S81



CAUTION

To prevent possible hearing damage, do not listen at high volume levels for long periods.

©2020. All rights are reserved. No part of this document may be reproduced without permission.

While all efforts have been made to ensure the accuracy of all the contents in this manual, we assume no liability for errors or omissions or statements of any kind in this manual, whether such errors or omissions or statements resulting from negligence, accidents, or any other cause. The contents of this manual are subjected to change without notice.

Protect our environment! We strive to produce products in compliance with global environmental standards. Please consult your local authorities for proper disposal.

Note: User Manual is just to guide the users about the functionality of the tablet. It is not a certificate of technology. Some functions may vary due to modifications and upgrade of software, or due to print mistake.

1. Tablet layout

1.1 . Tablet protective shell

The protective shell and the product are integrated.

If disassembled, the product will be damaged.



2. Getting started

Please read the safety instructions in the "Safety Information and Notices" section before use.

2.1. Inserting the SIM & SD card

- Using the SIM ejector Pin, gently pull out the SIM/ SD card tray from the slot
- Place SIM card and SD card on the respective slots
- Gently insert the tray with SIM and or SD card back into the Slot

3. Safety Information and Notices

3.1. For your safety

- Switch off the tablet in hospitals and aircraft. Obey any restrictions. Wireless devices can affect the medical treatment and cause interference in aircraft.
- Some medical devices such as hearing aids and pacemaker may be sensitive to external radio frequency emissions. Consult the device manufacturers or your doctor before using the tablet around the medical devices.
- Pay special attention to the ring tone volume and vibration settings if you have a heart problem.
- In areas with potentially explosive atmosphere, such as gas stations, fuel or chemical transfer or storage facilities, obey all signs and instructions.
- Your tablet will emit radio frequency even in the standby mode. Turn off your tablet when so instructed.

- Always obey all the local laws and regulations. Do not use your tablet while driving. Use Hands-free operation, if available, and give full attention to driving and to the road. Pull off the road before making or answering a call if you are driving.
- If your tablet is lost or stolen, notify your service provider immediately to stop the SIM card from being used.
- To prevent your tablet from misuse, lock your SIM card or tablet, and change passwords when necessary.
- When you leave your vehicle, take the tablet with you or place it in the glove compartment to avoid theft.
- Keep the tablet or charger out of reach of children.

Notes on tablet usage

- Your tablet will give off electromagnetic waves. Do not place it near storage medium such as floppy disk.
- Using the tablet near television, land tablet, radio and office automatic devices may cause interference and affect the function of the mobile tablet.
- Keep the tablet dry; all kinds of liquid can erode electronic circuit.
- Keep the tablet away from extreme temperatures.
- Keep the tablet away from fire or a lighted cigarette.
- Do not paint the tablet.
- Do not drop the tablet or violently crush or shake the tablet.
- Do not keep the tablet near magnets and other object with magnetism. The tablet's magnetism may clear the information stored on floppy disk, pre-paid tablet card and credit card.
- Keep the tablet away from hot places where the temperature may exceed 60°C, such as dashboard, windowsill, or areas exposed to direct sunlight.
- Do not disassemble or modify your tablet. This can damage the tablet, cause leakage and break the internal circuit.
- Use only damp cloth or non-static cloth to clean your tablet.
- Do not use alcohol, thinner, benzene or other chemicals or abrasive cleaner to clean your tablet.
- The tablet will become warm under normal use and while in battery charging.
- Do not leave the tablet with the battery empty for a long period of time. This may cause data loss.
- The metal parts of the tablet may irritate your skin depending on your health condition.
- Do not put the tablet in the back pocket. Sitting on it may damage the tablet. Do not put the tablet at the bottom of a bag. You may crush it.
- When the vibrate mode is on, place the tablet carefully to prevent it from being dropped from a height or being moved to a heat source due to the

vibrating.

- Do not press the touch screen with needles, pen point or other sharp objects; it can damage the display and violate the terms and conditions of the warranty.

Notes on battery usage

- Keep metal objects (such as coins or key rings) away from the battery to avoid short circuit.
- Do not remove the battery without turning off the tablet.
- Do not hold the battery in your mouth. The liquid of the battery can be toxic.
- Embedded battery shall be replaced by authorized dealers. Use only batteries approved by the tablet manufacturer; otherwise, it may cause explosion.
- Damage resulting from using un-authorized batteries and chargers will not be covered by the warranty.
- Avoid contact with any leaked liquid of the battery. If it touches your skin, wash your skin with fresh water and go to the hospital immediately.

Certification Information (SAR)

- Your tablet is designed not to exceed the limits of emission of radio waves recommended by international guidelines. These guidelines include safety margins designed to assure the protection of all persons, regardless of age and health.
- SAR (specific absorption rate) is the unit of body-absorbed RF quantity when the tablet is in use. SAR value is ascertained according to the highest RF level generated during laboratory tests.
- The true SAR level during tablet usage will be far lower than this level.
- The SAR value of the tablet may change depending on factors such as how close you are to a network tower, use of accessories and other enhancements.
- The highest SAR value of the device is less than 1.6W/Kg averaged over 1 gm of human tissue.
- The SAR value may differ depending on national reporting, testing requirements and the network band.

SAR Recommendations

- Use a wireless hands-free system (earphone) with a low power Bluetooth emitter.
- Please keep your calls short and use SMS whenever more convenient. This advice applies especially to children, adolescents and pregnant women.

- Prefer to use your cell tablet when the signal quality is good.
- Maintain a preferable distance of 15 mm from the device.

Safety precautions:

- Use tablet when the signal quality is good
- Use a wireless hands-free system (Earphone, headset) with a low power Bluetooth emitter
- Make sure the cell tablet has a low SAR
- Keep your calls short or send a text message (SMS) instead. This advice applies especially to children, adolescents and pregnant women.

E-waste Disposal Mechanism

'E-waste' means waste electrical and electronic equipment (WEEE). In other words, E-waste is a popular, informal name for electronic products nearing the end of their "useful life". For more details about e-waste please refer e-waste rules, 2011 www.moef.nic.in

Do's and Don'ts for disposal e-waste

Do's:

- Ensure that an Authorized Person repairs your Lava products
- Call Our Local Authorized Collection Centers to Dispose Lava products
- Always drop your used electronic products, batteries or any accessories thereof after the end of their life at nearest Authorized Collection Point or Collection Center.
- Separate the packaging material according to responsible waste disposal options and sorting for recycling.
- Always remove the battery from the product, when you do not intend to use the product anymore it in future.

Don'ts:

- Do not Dismantle your Lava Product on your own
- Do not give your e-waste to Scrap Dealer/ Rag Pickers.
- Do not dispose-off the e-waste in landfills
- Never dump E-waste in garbage bins.
- Do not dispose of your product at municipal waste bins or rooms.
- Do not throw used batteries into household waste.

Consequences of improper handling and disposal of E-Waste

- Improper disposal of waste prevents natural resources from being re-used.
- Some waste contains hazardous chemicals and if not disposed of properly may release toxins into the soil and water, and also releases greenhouse gases into the environment
- If e-waste is not properly disposed of, it can be a threat to health and

well-being of humans and animals and it also has adverse effect on the environment.

- Placing of batteries or devices on or in heating devices, such as microwave, ovens, stoves, or radiators and improper disposal of batteries may lead to explosion.
- If the battery terminals are in contact with metal objects, it may cause a fire.

For more details on how to dispose of your Lava products at the end of life, please refer the list of our Services Centers on Pan basis on our website

www.lavamobiles.com

4. Copyrights

Google is a trademark of Google LLC.

5. LAVA support and contact information

LAVA support and contact Information

Visit: <http://www.lavamobiles.com> for additional information downloads and services related to your LAVA product.

To check for the nearest LAVA service center location for maintenance services, please visit:

<http://www.lavamobiles.com/support>

Service Center number

1860-500-5001

(Available from Monday to Saturday, between 10:00AM to 6:00PM)

For any service related enquiries please contact us at: lavacare@lavainternational.in

FCC Statement

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with part 15 of the FCC Rules.

Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and**
- (2) This device must accept any interference received, including interference that may cause undesired operation**

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.**
- Increase the separation between the equipment and receiver.**
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.**
- Consult the dealer or an experienced radio/TV technician for help.**

RF Exposure Information

SAR tests are conducted using standard operating positions accepted by the FCC with the device transmitting at its highest certified power level in all tested frequency bands, although the SAR is determined at the highest certified power level, the actual SAR level of the device while operating can be well below the maximum value.

Before a new device is available for sale to the public, it must be tested and certified to the FCC that it does not exceed the exposure limit established by the FCC, Tests for each device are performed in positions and locations as required by the FCC. For body worn operation, this device has been tested and meets the FCC RF exposure guidelines when used with an accessory designated for this product or when used with an accessory that Contains no metal .

Non-compliance with the above restrictions may result in violation of RF exposure guidelines.