


文件编码(material code) : B6C-US-344-001

打样版本	修改内容	修改人	日期	受控版本	备注
V1	新图发布	胡晨翔	2018.11.28		
V2	修改内容	胡晨翔	2018.11.30		
V3	修改内容	胡晨翔	2018.12.01		
V4	修改图片	胡晨翔	2018.12.06		
V5	增加客户信息	胡晨翔	2018.12.19	A0	


正面



blackweb
WALMART
WIRELESS CHARGING
MOUSE PAD
MODEL: BWA19HO008
PRODUCT GUIDE
Ver 01 Rev 01/01/19

Welcome Guide
Wireless charging mouse pad

Contents:
Before getting started, ensure the package contains the following components:




Safety and Compliance
Read all the instructions before using the product.

- To reduce the risk of injury, close supervision is necessary when the product is used near children.
- Don't put finger or hand into product.
- Do not expose product to rain or snow.
- Use of a power supply or charger not recommended or sold by this product manufacturer may result in a risk of fire or injury to persons.
- Do not use the wireless charging mouse pad in excess of its output rating. Overload outputs above rating may result in a risk of fire or injury to persons.
- Do not use the wireless charging mouse pad that is damaged or modified. Damaged or modified charging pad may exhibit unpredictable behavior resulting in fire, explosion or risk of injury.
- Do not disassemble the wireless charging mouse pad. Take it to a qualified service person when service or repair is required. Incorrect assembly may result in a risk of fire or injury to persons.
- Do not expose the wireless charging mouse pad to fire or excessive temperature. Exposure to fire or temperature above 100°C may cause explosion.
- Disconnect the cable from AC adapter or laptop when wireless charging mouse pad not in use.
- If your wireless charging mouse pad will not be used for an extended time, please store it in a cool and dry place to avoid damaging the product.

Protection
Your wireless charging mouse pad has overvoltage protection, under voltage protection, over current protection, short circuit protection, temperature control and foreign object detection. Charging stops in above situation in order to protect your wireless charging mouse pad and connected device.

Connect Charging Pad to Power Source



- Plug the included micro USB connector of charging cable into the input port on your wireless charging pad.
- Plug the USB-A connector into a power source, like an AC adapter(not included) or a USB-A female port of a laptop.
- The LED will turn on solid blue light.


190mm

双面印刷

印刷尺寸 : 256*190mm
成品尺寸 65*95mm
折叠方式 : 风琴折
材质 : 80g书纸

背面

Charging Devices



Put your Qi-enabled phone on the center of wireless charging area on charging pad and not moved. The distance can be charged is less than 10mm.

Note:

- To charge your device we recommend that you use the original cable(included) for wireless charging input.
- Using other cables may significantly reduce the charging speed(or prevent the charging altogether).
- To stop the charging process, disconnect the cable from your charging pad, the wireless charging mouse pad will automatically turn off.

LED Indicator

LED Indicator	Your wireless charging mouse pad
Blue (Solid)	Stand-by or phone is fully charged
Blue (Pulse)	Wireless charging active
Red	Problem with wireless charging

Troubleshooting
My charging pad doesn't charge.

- Make sure that the USB charging cable is connected correctly.
- If you're using an AC power outlet, make sure that the outlet is properly powered.
- If you're using a laptop USB port, make sure that the laptop is turned on and the USB port is properly powered.
- If none of the above solves the issue, your charging pad may be damaged. Replace your charging pad.

My charging pad doesn't charge a device

- Make sure that your phone is Qi-enabled.
- Make sure that your phone is centered on the wireless charging area on the charging pad. See chapter **Charging devices**.
- Make sure that your charging pad is connected to a power source correctly. See chapter **Connect Charging Pad to Power Source**.
- Your wireless charging mouse pad has overvoltage protection, under voltage protection, over current protection, short circuit protection, temperature control and foreign object detection. Charging stops in above situation in order to protect your wireless charging mouse pad and connected device.

Specifications

Number of Coil	1 coil
Input	Micro USB 5V/2A
Rated output	Wireless 5W standard charging
Protection function	Over voltage, under voltage, temperature control, over current, short circuit, foreign object detection
LED	LED indicator
Housing	Plastic+fabric
Working temperature	32 ~104 °F (0~40 °C)
Dimensions (L x W x D)	13.5x9.06x2.65 in. (343x230x65mm)
Weight	8.25 oz (234g)

Disposal

Electronic devices are recyclable waste and must not be disposed of in the household waste. At the end of its service life, dispose of the product according to the relevant statutory regulations. The built-in rechargeable battery must be disposed of by a specialist.

Qi The Qi symbol is a trademark of the Wireless Power Consortium Designed for Qi compliance

FCC This equipment has been tested and found to comply with the limits for a WPC device, pursuant to Part 18 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

blackweb
Walmart Inc., Bentonville, AR 72716
Hotline: 1-800-925-6278
MADE IN CHINA

设计(design): 胡晨翔
审核(check):
批准(approve):
版本(version): V1

数量(quantity): 1
单位(units): mm
比例(scale): 1:1
页数(page): 1

产品型号(model): WC-044
产品名称(name): 无线鼠标垫
包装类型(type): 说明书
设计日期(date): 2018.11.28

颜色(colour): 白底黑字
尺寸(size): 如图
材料(material): 80g书纸
表面处理(surface finish): //