Function

A. You can chat with your friends through hands-free function to make phone calls on your mobile device or tablet.

B. Built-in 240mAh lithium battery, which can play for 2-3 hours.

C. Portable and convenient, suitable for both indoor and outdoor sports.

Power On

Long press the power button to turn on the Bluetooth sound.

Charging

Connect the speaker to the USB jack on the computer or use the USI charger to charge it through the USB charger.

Attention: Normally, please use the 1.5a mobile phone charger, whic can avoid damage to the machine.


Wireless Connection

A. When the power is turned on, the device defaults to Bluetooth waiting for pairing.

B. Turn on the Bluetooth of the mobile phone, search for the pairing name "BT SPEAKER", and click the connection to be paired successfully.C. It is normal for some mobile phones to wait 10 seconds for the pairing name to appear when searching for it.

Buttons

- (1) TF Card Slot
- 2 Mic
- ③ USB Interface
- ④ Turn On/Off
- **(5)** Mode Switch (Bluetooth or TF card)
- 6 Volume Reduction/ Last Song
- ⑦ Play/Pause/Talk
- 8 Volume up/Next song



FCC STATEMENT :

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and

(2) This device must accept any interference received, including interference that may cause undesired operation.

Warning: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Reorient or relocate the receiving antenna.

Increase the separation between the equipment and receiver.

Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

Consult the dealer or an experienced radio/TV technician for help.

RF warning statement:

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.