


PDW30100 英文说明书
展开尺寸：105*406mm
成品尺寸：105*58mm
颜色：4C+4C
材质：128g 双铜纸
备注：双面印刷



Bluetooth Device Charging Mode

Bluetooth Device Charging Mode is a special mode for charging Bluetooth headphones or smart watches, which require low input power.

- Connect Bluetooth headphones or smart watches to USB-A / USB-C socket of NitroCharge 30.
- Enter into Bluetooth Device Charging Mode by pressing twice on the Mode button, "%" symbol blinks in the mode.
- Return to Normal Mode by pressing twice on the Mode button. Or it will automatically turn back to Normal mode in 3 hours, and "%" symbol stops blinking in Normal Mode.

Recharging NitroCharge 30

- NitroCharge 30 goes off when the battery level goes to "0".
- Connect the provided USB-C to USB-C or USB-C to USB-A cable into USB-C socket of NitroCharge 30.
- Connect other end of cable to a power source. 30W (or greater) USB-C type charger is recommended to charge NitroCharge 30 at the highest recharging speed.
- Last digit number of the battery level blinks while NitroCharge 30 is being recharged.

Product Specification

Model	PDW30100 (NitroCharge 30)
Capacity	10,000mAh / 37WH
Battery	Lithium Polymer Battery
USB-C Input	MAX 30W 20V=1.5A, 15V=2A, 12V=2.5A, 9V/5V=3A
USB-C Output	MAX 33W 20V=1.5A, 15V=2A, 12V=2.5A 9V/5V=3A PPS: 3.3V-11V=3A
USB-A Output	MAX 18W 12V=1.5A, 9V=2A, 5V=3A
Wireless Output	MAX 10W

Attention

- Do not throw, drop or physically damage the product for safety.
- Do not place in a closed or sealed place.
- Avoid storage in high humidity, high temperature or exposure to fire.
- Do not expose the product to direct sunshine or liquids.
- Please keep the input and output ports clean.
- Make sure people who are inexperienced or mentally and physically disabled do not use the product unless they are offered appropriate supervision or guidance.
- Keep the product out of the reach of children.

Note

Before using the product, please read this user guide carefully.

- Use of a power supply or charger not recommended by EXCITRUS may result in a risk of fire or injury to persons.
- To give your NitroCharge 30 the fastest, safest recharge, use a compatible EXCITRUS USB-C PD charger.
- To preserve battery NitroCharge 30 lifespan, use and recharge at least once every 3 months.
- Please remove the cable once the power bank is fully charged.
- Please keep the power bank in a cool and dry place.
- Do not place or use the power bank at high temperature or in sealed or humid environment.

CAN ICES-3(B)/NMB-3(B)

FCC compliance statement

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- this device may not cause harmful interference, and
- this device must accept any interference received, including interference that may cause undesired operation.

changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

ISED compliance statement

This device contains licence-exempt transmitter(s)/ receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions:

- This device may not cause interference.
- This device must accept any interference, including interference that may cause undesired operation of the device.

L'émetteur/récepteur exempt de licence contenu dans le présent appareil est conforme aux CNR d'Innovation, Sciences et Développement économique Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes :

- L'appareil ne doit pas produire de brouillage;
- L'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

Radiation Exposure statement

This equipment complies with FCC/IC RSS-102 radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20 cm between the radiator and your body. Cet équipement est conforme aux limites d'exposition aux radiations FCC/IC CNR-102 établies pour un environnement non contrôlé. Cet équipement doit être installé et utilisé avec une distance minimale de 20 cm entre le radiateur et votre corps.

IMPORTANT SAFETY INSTRUCTIONS


WARNING – When using this product, basic precautions should always be followed, including the following:

- Read all the instructions before using the product.
 - To reduce the risk of injury, close supervision is necessary when the product is used near children.
 - Do not put fingers or hands into the product.
 - Do not expose power bank to rain or snow.
 - Use of a power supply or charger not recommended or sold by power pack manufacturer may result in a risk of fire or injury to persons.
 - Do not use the power bank in excess of its output rating. Overload outputs above rating may result in a risk of fire or injury to persons.
 - Do not use the power bank that is damaged or modified. Damaged or modified batteries may exhibit unpredictable behavior resulting in fire, explosion or risk of injury.
 - Do not disassemble the power bank. Take it to a qualified service person when service or repair is required. Incorrect reassembly may result in a risk of fire or injury to persons.
 - Do not expose a power pack to fire or excessive temperature. Exposure to fire or temperature above 100°C may cause explosion. The temperature of 100°C can be replaced by the temperature of 212°F.
 - Have servicing performed by a qualified repair person using only identical replacement parts. This will ensure that the safety of the product is maintained.
 - Switch off the power bank when not in use.
- SAVE THESE INSTRUCTIONS

Apply Magnetic Metal Sticker

Magnetic Metal stickers inside phone case helps phone positioning when wireless charging.

- Select the size of positioning card according to your phone size (keep/tear off the dotted area).
- Place this positioning card in the middle of the phone case with the side facing up.
- Stick the magnetic metal stickers on two positioning holes;
- Remove the positioning card after finishing sticking.



Wireless Charging (for enabled devices)

- Press Mode Button on NitroCharge 30.
- Center device on NitroCharge 30.
- “f” blinks when charging begins.

版本V1.1.7