User Manual Bluetooth 5.0 Audio Adapter

Product Introduction

This product is a Bluetooth Audio Adapter, power supply and audio output as one. The shell is made of zinc alloy material, it can provide Bluetooth function for speakers and cars without Bluetooth function, audio from mobile devices such as mobile phones and tablets can be transmitted to the speakers or cars via this adapter.

Product specification

Name	Bluetooth 5.0 Audio	BT version	5.0
	Adapter		
SNR	92dB	Frequency	20Hz~20KHz
Power Supply	500mA	Range	10m
Temperature	-10°C~50°C	Humidity	≤90%

Features

- Bluetooth 5.0 Version
- High Sensitivity Microphone
- Creative small device

Installation Guide


- 1. Connect the USB power supply port of the product to the charger and power on automatically.
- 2. Connect the 3.5mm audio jack to your speaker or car via AUX port.

Connection Guide

- 1. The Audio Adapter will automatically enter pairing mode once power on. .
- 2. Open the Bluetooth function on your mobile phone or tablet and click search.
- 3. Click "Palovue Linkflow" once appear.
- 4. The Audio Adapter will automatically re-connect next time once power on.

Note: The pairing mode lasts only 3 minutes. After 3 minutes, the LED lights will enter the slow flash standby mode. If you need to enter the pairing mode, please restart the product after power failure.

Product Diagram



FAQ

Q: How much power is needed?

A: Please use 5V/500mA power supply. If the current is too high, the equipment may be damaged.

Q: Will there be an electric current sound?

- A: This will happen to a few users. Current noise is usually caused by power supply, and different vehicle noise will be different. If it occurs, it can be avoided by following settings.
- 1. Turn the car down and the mobile phone up.
- 2. Try to use the car with its own USB power supply or mobile power supply, do not use the cigarette lighter car charging, because the cigarette lighter is the engine power supply, the current is unstable.

Package Content

- Bluetooth 5.0 Audio Adapter
- User Manual

FCC Warning

Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user authority to operate the equipment.

Notes: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If

this equipment does cause harmful interference to radio or television reception, which can

be determined by turning the equipment off and on, the user is encouraged to try to correct

the interference by one or more of the following measures:

-- Reorient or relocate the receiving antenna.

-- Increase the separation between the equipment and receiver.

-- Connect the equipment into an outlet on a circuit different from that to which the receiver

is connected.

-- Consult the dealer or an experienced radio/TV technician for help.

Note: If shielded cables or special accessories are required for compliance, a statement must

be included which instructs the user to employ them, for example, Shielded cables must be

used with this unit to ensure compliance with the Class B FCC limits.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two

conditions:

(1) this device may not cause harmful interference.

(2) this device must accept any interference received, including interference that may cause undesired

operation.

Support

If you encounter any issues during operation, please simply scan below QR Code to ask

for support. We will make things right for you within 48 hours.

Email: support@palovue.net

Website: www.palovue.com