




Band Edge NVNT ac40 5230MHz High Ant2




Band Edge NVNT ac40 5755MHz Low Ant1




Band Edge NVNT ac40 5755MHz Low Ant2




Band Edge NVNT ac40 5795MHz High Ant1




Band Edge NVNT ac40 5795MHz High Ant2




Band Edge NVNT ac80 5210MHz Low Ant1




Band Edge NVNT ac80 5210MHz Low Ant2




Band Edge NVNT ac80 5775MHz High Ant1




Band Edge NVNT ac80 5775MHz High Ant2




Band Edge NVNT n20 5180MHz Low Ant1




Band Edge NVNT n20 5180MHz Low Ant2




Band Edge NVNT n20 5240MHz High Ant1




Band Edge NVNT n20 5240MHz High Ant2




Band Edge NVNT n20 5745MHz Low Ant1




Band Edge NVNT n20 5745MHz Low Ant2




Band Edge NVNT n20 5825MHz High Ant1




Band Edge NVNT n20 5825MHz High Ant2




Band Edge NVNT n40 5190MHz Low Ant1




Band Edge NVNT n40 5190MHz Low Ant2




Band Edge NVNT n40 5230MHz High Ant1




Band Edge NVNT n40 5230MHz High Ant2




Band Edge NVNT n40 5755MHz Low Ant1




Band Edge NVNT n40 5755MHz Low Ant2



Band Edge NVNT n40 5795MHz High Ant1



Band Edge NVNT n40 5795MHz High Ant2




7.7 Frequency Stability

Condition	Mode	Frequency (MHz)	Antenna	Measured Frequency (MHz)	Frequency Error (Hz)	Deviation (ppm)	Limit (ppm)	Verdict
NVNT	a	5180	Ant1	5180	0	0	25	Pass
NVNT	a	5200	Ant1	5199.98	-20000	-3.85	25	Pass
NVNT	a	5240	Ant1	5240	0	0	25	Pass
NVNT	a	5745	Ant1	5744.98	-20000	-3.48	25	Pass
NVNT	a	5785	Ant1	5784.98	-20000	-3.46	25	Pass
NVNT	a	5825	Ant1	5825	0	0	25	Pass
NVNT	a	5180	Ant2	5180	0	0	25	Pass
NVNT	a	5200	Ant2	5199.98	-20000	-3.85	25	Pass
NVNT	a	5240	Ant2	5240	0	0	25	Pass
NVNT	a	5745	Ant2	5744.98	-20000	-3.48	25	Pass
NVNT	a	5785	Ant2	5784.98	-20000	-3.46	25	Pass
NVNT	a	5825	Ant2	5825	0	0	25	Pass
NVNT	ac20	5180	Sum	5179.98	-20000	-3.86	25	Pass
NVNT	ac20	5200	Sum	5199.98	-20000	-3.85	25	Pass
NVNT	ac20	5240	Sum	5240	0	0	25	Pass
NVNT	ac20	5745	Sum	5745	0	0	25	Pass
NVNT	ac20	5785	Sum	5785	0	0	25	Pass
NVNT	ac20	5825	Sum	5824.98	-20000	-3.43	25	Pass
NVNT	ac40	5190	Sum	5190	0	0	25	Pass
NVNT	ac40	5230	Sum	5230	0	0	25	Pass
NVNT	ac40	5755	Sum	5755	0	0	25	Pass
NVNT	ac40	5795	Sum	5795	0	0	25	Pass
NVNT	ac80	5210	Sum	5210	0	0	25	Pass
NVNT	ac80	5775	Sum	5775	0	0	25	Pass
NVNT	n20	5180	Sum	5179.98	-20000	-3.86	25	Pass
NVNT	n20	5200	Sum	5200	0	0	25	Pass
NVNT	n20	5240	Sum	5239.98	-20000	-3.82	25	Pass
NVNT	n20	5745	Sum	5745	0	0	25	Pass
NVNT	n20	5785	Sum	5784.98	-20000	-3.46	25	Pass


NVNT	n20	5825	Sum	5825	0	0	25	Pass
NVNT	n40	5190	Sum	5190	0	0	25	Pass
NVNT	n40	5230	Sum	5230	0	0	25	Pass
NVNT	n40	5755	Sum	5755	0	0	25	Pass
NVNT	n40	5795	Sum	5795	0	0	25	Pass

BlueAsia


Freq. Stability NVNT a 5180MHz Ant1




Freq. Stability NVNT a 5200MHz Ant1




Freq. Stability NVNT a 5240MHz Ant1




Freq. Stability NVNT a 5745MHz Ant1




Freq. Stability NVNT a 5785MHz Ant1




Freq. Stability NVNT a 5825MHz Ant1




Freq. Stability NVNT a 5180MHz Ant2




Freq. Stability NVNT a 5200MHz Ant2




Freq. Stability NVNT a 5240MHz Ant2




Freq. Stability NVNT a 5745MHz Ant2




Freq. Stability NVNT a 5785MHz Ant2




Freq. Stability NVNT a 5825MHz Ant2




Freq. Stability NVNT ac20 5180MHz Sum




Freq. Stability NVNT ac20 5200MHz Sum




Freq. Stability NVNT ac20 5240MHz Sum




Freq. Stability NVNT ac20 5745MHz Sum



Freq. Stability NVNT ac20 5785MHz Sum



Freq. Stability NVNT ac20 5825MHz Sum



Freq. Stability NVNT ac40 5190MHz Sum