





Bluetooth TV Soundbar EBT-1154B



REMOTE CONTROL



IN THE BOX




SPECIFICATION

- Bluetooth: 5.0
- Speaker: 5 W*2
- Function: BT AUX USB
- Dimensions: 810*80*74 mm

1


LOCATION OF CONTROLS



1. ON/OFF
2. Mode: Switch AUX, USB, Bluetooth
3. Previous song/Voice down
4. Play/Pause
5. Next song/Voice up
6. Input AUX
7. USB: U Disk
8. Micro input

2


LOCATION OF CONTROLS



1. ON/OFF
2. Switch AUX, USB, Bluetooth
3. Mute
4. Previous song
5. Play/Pause
6. Next song
7. Voice down
8. Reset settings
9. Voice up

MOUNTING THE SPEAKER

1. Measure a width of 26.77 inches on the wall.
2. Mark the position of the mounting screws on the wall using a pencil.
3. Drill the supplied screws directly into the marks that you have made on the wall and leave approximately 0.3 inch length to hook the Wireless Sound Bar.
4. Put the Wireless Sound Bar onto the mounting screws. Make sure they are firm and stable.



3

OPERATION PROCESS

1. Connect to Micro input port
2. Long press the [POWER] button on the speaker or Short press the remote control switch to turn on the speaker.
3. LED indicator lights flash blue and a "The bluetooth ready to pair" sound is heard, then go into bluetooth pairing mode.
- 3.1 During the pairing process, keep the speaker and bluetooth device within 10 meters of each other.
- 3.2 Set your phone or other bluetooth device to bluetooth status.

BLUETOOTH CONNECTION METHOD FOR ANDROID SYSTEM:

1. Go to SETTINGS-> BLUETOOTH (make sure bluetooth is turned ON)
2. When your bluetooth enabled device find the speaker, select "Monster Bluetooth Soundbar" from the list of found devices. When succeeding pairing, you will hear "The bluetooth device is connected successfully". Blue LED indicator light bright on. When play the music, the blue led indicator flashes

4

OPERATION PROCESS

3.2 U DISK MODE OPERATION

3.2.1 Insert the U disk into the USB port, the blue light flashes slowly, Enter U Disk Channel

3.3 AUX MODE OPERATION

3.3.1 Insert one of the connection ports of the audio cable into the [AUX] jack, and then insert another connection port into the socket of the media playback device.

3.3.2 Press the (Power) button on the speaker or the remote control. When indicator lights up Red light

3.3.3 Short press the [MODE] button on the speaker to remote control switch to AUX mode. When indicator lights flash Red light, enter AUX Channel.

3.4 VOLUME CONTROL OPERATION

3.4.1 Short press the [-] button on the speaker or the [-] button on the remote control to reduce the volume and Long press to previous track.

3.4.2 Short press the [+] button on the speaker or the [+] button on the remote control to increase the volume and long press skip to next track.

5

CAUTIONS AND WARNINGS:

1. Do not use the bluetooth speaker near water or humid; do not use the device near the bathtub, water tank, swimming pool and so on.
2. Do not install the bluetooth speaker in the hot or cold environment.
3. Do not expose the device in the sunshine directly.
4. Do not use the device near fire, such as, stove, candle or fireplace and so on.
5. Do not use abrasive cleaning solvents to clean the bluetooth speaker.

6

FCC WARNING RO:

1. P This device complies with part 15 of the FCC Rules.

Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio

communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

Consult the dealer or an experienced radio/TV technician for help. The device has been evaluated to meet general RF exposure requirements

To maintain compliance with FCC's RF Exposure guidelines, This equipment should be installed and operated with minimum distance between 20cm the radiator your body.

FCC ID: 2ASO-1154B

7