

## SPECIFICATIONS

**Model No:** QC0044

**Input:** 5V/2A, 9V/1.67A

**Output Power:** 5V/1A,9V/1.1A

**Charging efficiency:** 75%

**Charging distance :** ≤8MM

**Materials:** PU

## REALSIMPLE

Real Simple™ is a registered trademark of Meredith Corporation and operated under license.

Designed in New York. Made in China.  
New York NY 10018 | support@argentosc.com | www.argentosc.com



### FCC Disclaimer:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help or assistance.

This device complies with Part 15 of the FCC Rules and Industry Canada license-exempt RSS standard(s). Operation is subject to the following two conditions:

- 1- This device may not cause harmful interference, and
- 2- This device must accept any interference received, including interference that may cause undesired operation. The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. Such modifications could void the user's authority to operate the equipment. Under Industry Canada regulations, this radio transmitter may only operate using an antenna of a type and maximum (or lesser) gain approved for the transmitter by Industry Canada. To reduce potential radio interference to other users, the antenna type and its gain should be so chosen that the equivalent isotropically radiated power (e.i.r.p.) is not more than that necessary for successful communication.

FCC RF exposure statement:  
The equipment complies with FCC Radiation exposure limit set forth for uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator and your body.

### Electronic and electrical devices disposal

This symbol indicates that electrical and electronic device is to be collected separately.




- This product is designated for separate collection at an appropriate collection point. Do not dispose of as household waste.
- If the device use batteries, they must be removed from the device and disposed in a appropriate collection center.
- If the batteries cannot be removed, do not attempt to do it yourself since it must be done by a qualified professional.
- Separate collection and recycling helps conserve natural resources and prevent negative consequence for human health and the environment that might result from incorrect disposal.
- For more information, contact the retailer or the local authorities in charge of waste management.

# REALSIMPLE

## MOUSE PAD WITH WIRELESS CHARGER


IMPORTANT: PLEASE READ BEFORE USING THIS PRODUCT

## PRODUCT FEATURES




## HOW TO USE THE WIRELESS CHARGER?

1. Connect the wireless charger to a power source using the Micro-USB cable.
2. To charge a device, place it in the center of the wireless charger. Indicator light will stay lit while charging.
3. When your device is completely charged, remove the device from the charging pad.



Correct



Wrong

## IMPORTANT SAFETY INSTRUCTIONS

Failure to follow the safety instructions can lead to fire, electrical shock, personal injury or property damage or damage to this product. Make sure to read the entire manual.

1. Using the included micro-USB cable, connect to a computer or wall charger (sold separately) to enable wireless charging. The LED light will show red when it is connected successfully.
2. Make sure your phone is compatible for wireless charging.
5. Place your phone in the center of the charging plate. The LED light will show blue when it is charging.
6. Do not handle the unit, USB cord or wall charger with wet hands. Do not allow water or liquids to be exposed to the product.
7. Do not leave the product in a hot location.
8. Do not disassemble, modify, repair this product.

9. Repairs to electrical equipment should only be performed by a qualified electrician. Improper repairs may place the user at serious risk.
10. Do not place any metallic items on the surface of the product.
11. If a non Qi compatible device is used, charger may overheat
12. Disable vibration features while charging to ensure vibration does not move the device and lose charge.
13. Multiple Qi enabled devices cannot be charged at the same time.

## CLEANING

If the Charging Pad needs cleaning, wipe it using a soft, dry cloth. Never use any abrasive cleaning agents. Periodically wipe off any accumulated dust.