

## WARNING

### Please read carefully before using:

- This product is not a toy. Please keep it out of reach of children
- Do not throw the product
- Do not throw it into a fire. Keep it away from extreme heat because of the built-in battery is flammable
- To avoid getting an electric shock, do not charge the product while it is in water
- If you have any issues or questions about this product, please contact us at [cs@aduroproducts.com](mailto:cs@aduroproducts.com)

### Product Specifications

Speaker: 3W/4Ω	DC Input: DC 5 V/300mA
Lithium Battery: 3.7V/400mAh	Bluetooth Distance: About 30 ft.
Playtime: About 4 Hours	
Charging Time: About 3 Hours	




# WIRELESS POOL FLOAT SPEAKER

Works With All Bluetooth®  
Enabled Devices

## Instruction Manual

## Product Overview



### To Pair/Connect Your Phone

1. Long press the on/off button for 3 seconds and the speaker will turn on.
2. Turn on the Bluetooth setting on your phone or tablet.
3. Find the device name "ANX POOL FLOAT" and select it to connect it. The speaker will say, "The Bluetooth device is connected successfully" when it is paired with your device.

### To Charge The Battery:

This product is powered by an integrated rechargeable lithium battery, a USB charging cable is included.

### Charge the battery as follows:

1. Remove the speaker from the float .
2. Insert the charging cable into the USB port on the speaker.
3. Connect the USB plug into a PC or ACDC adapter. When the red LED indicator starts to flash, the battery is charging. It will take approximately 3 hours to fully charge the battery.
4. When the battery is fully charged the LED indicator light will go out. Remove charging cable from the speaker. Make sure to firmly secure the protective rubber stopper to protect the speaker from water damage.

## FCC Warning Statement

This device complies with part 15 of the FCC R5ules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment.  
This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

