


Bike Speaker 说明书

成品尺寸: 45x45x45mm

装订方式: 三折页 (黑白正反面印刷)

材质: 100g铜版纸

<p style="text-align: center;">Glory Star L15</p> <hr/> <p style="text-align: center;">Bluetooth headphone</p> <p style="text-align: center;">User Manual</p> 	<p>Specifications</p> <p>Bluetooth version: V5.4 Earbud Bluetooth solutions: JL7003 Case Bluetooth solutions: JL7012 Bluetooth working frequency: 2.402GHz-2.480GHz Frequency response: 20Hz-20KHz Earbud battery capacity: 40mAh Charging case battery capacity: 400mAh Speaker size: 13mm Effective distance: 10M Play time: Up to 6hours Charging time: 4-5hours</p> <p>What's in box?</p> <p>1 x Charging cable 1 set Eartips</p>	<p>Bluetooth Pairing</p> <ol style="list-style-type: none">1. The earbuds will automatically enter the searching and pairing mode when turned on2. Open the Bluetooth settings on your phone to search and pair the speaker. Pairing name: "L15-BK"3. After paired successfully, your phone's audio will play through the earbuds <p>Warning:</p> <p>Read the below warning thoroughly before using your earbuds. Store this manual with product packaging.</p> <p>To reduce the risk of injury:</p> <ol style="list-style-type: none">1. Keep batteries out of reach of children.2. Do not heat, open, or dispose of battery pack in fire.3. Do not allow metal objects to touch the battery on the device.4. Do not expose battery pack to excessive heat.
---	---	--

<p>Charging Function:</p> <p>Fully charge the case and earbuds before using for the first time.</p> <p>Case Charging:</p> <ol style="list-style-type: none">1. Connect the included USB-C cable to the Type-C charging port of the earbud case and the other end into a USB power source to charge your case. <p>Earbud Charging:</p> <ol style="list-style-type: none">1. When the earbud battery is low, it will prompt "battery low" every minute. The earbuds will turn off completely when the batteries are fully discharged.2. Place the earbuds into the charging case and close the case. The charging case will automatically charge the earbuds, and the display on the charging case will show a charging symbol. <p>Power On/off:</p> <ol style="list-style-type: none">1. Open the charging case, and take out the earbuds, the earbuds will turn on automatically2. Place earbuds into the charging case and close the case to turn off.	<p>Play/Pause Music</p> <ol style="list-style-type: none">1. When listening to music, tap the left or right earbud once to play or pause the music. <p>Previous/Next Song</p> <ol style="list-style-type: none">1. When listening to music, double tap the left or right earbud to skip to the previous song2. Triple tap the left or right earbud to skip to the next song <p>Volume - / +</p> <ol style="list-style-type: none">1. When listening to music, slide finger down the left or right earbud to decrease the volume2. Slide finger up the left or right earbud to increase the volume <p>Incoming Phone Calls</p> <ol style="list-style-type: none">1. Tap left or right earbud once to answer or hang up2. Tap left or right earbud twice to reject the call <p>Voice Assistant:</p> <ol style="list-style-type: none">1. Tap left or right earbud 4 times to activate voice assistant	<p>NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:</p> <ul style="list-style-type: none">- Reorient or relocate the receiving antenna.- Increase the separation between the equipment and receiver.- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.- Consult the dealer or an experienced radio/TV technician for help <p>Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.</p> <p>This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.</p> <p>FCC ID: 2AS7V-L15</p>
---	---	--