Amoi earphone Q5

FCC ID: 2ASCI-HBM306Q5



Instructions Please read the user manual before use

Product usage and introduction

1. Do not try to disassemble or replace any parts in the product except for the operation mode specially labeled in the manual.

2. Do not put the product into water or any other liquid. The product is not waterproof.

3. If any liquid enters the product accidentally, disconnect and remove the product immediately.

4. In order to avoid electric shock, please ensure that there is no water on your hands when installing or unloading the product.

5. Do not place the product near the heat source or directly exposed to the fire source.

6. Do not place the product in the environment with strong


electromagnetic force, otherwise it will lead to product failure.

Introduction of packaging





Product schematic diagram



- ① On/Off button (touch area)
- ③ Type c charging port
- 2 Red blue indicator light

Product standard

BT version: V5.0 Transmission distance: ≥15M Battery capacity: 50mAh Service time: about 6 hours Charging time: about 1 hour Rated input:5V --- 50mA

LED Indicator Status

Headphone LED Indicator	 Power on: earphones alternately flash blue lights Shutdown: headphone lights go out Headset pairing: red and blue lights blink alternately Headset pairing: red and blue lights blink alternately Connecting to BT successfully: The blue light blinks slowly Low power: The headphone indicator blinks red quickly
----------------------------	--


Product operation Instructions

1. Long press the function key for 3 seconds, and the blue lights will flash alternately with a prompt tone.

2. Power off: Long press the function key for 3 seconds, the light will turn off, and a prompt tone will appear.

3. Pairing: After the headset is turned on, turn on the mobile phone, find the Settings in the mobile phone, and turn on BT.


BT search displays "Amoi earphone U5". After the connection is successful, the blue light blinks slowly, and the blue light goes off when the device plays normally




Touch button operation

Music Playback Mode

Right ear headset operation



Right ear headset operation (under incoming call)



Charging indicator

Connect the USB port to the DC5V charger socket, and connect the Type-C port to the headphone charging port Charging, charging indicator light long red light, full charge after the red light off.



The name and content of harmful substances in the earbuds

Part Names		Harmful Substances						
	Pb	Hg	Cd	Cr(VI)	PBB	PBDE		
Printed circuit assembly	0	0	0	0	0	0		
Small structural parts such as shel	0	0	0	0	0	0		
O:Indicates that the homogeneous ma GB/T 26572. X:Indicates that the homogeneous ma specified in GB/T The parts marked limitations of glob	terials of ne hazaro terial of 26572. with "X"	the part lous sub the part on the fo	t is in be stance a exceeds orm are a	low the lin t least in a The limit all harmful	nit requir certain requirem due to t	ed by ents he		
Printed circuit boo Including printed etc.and dependin may not contain a	circuit bo g on the	bards and product	model,tl	he earbud		5.32 (G)		
Peo num	tronic and electrical products sold in the ple's Republic of China must mark this LOGO,the ber in the logo represents the product under normal Environmental protection use period.							

WARRANTY STATEMENT

Disclaimer

This user manual does not have any form of guarantee, position expression or other implication.

The mentioned products, specifications and information are for reference only, and the content will also be updated on the web at any time without additional separate notice

Warranty statement:

The product attached to this document is guaranteed as follows: If the product is twelve (12) months from the date of purchase("Warranty Period"), under normal conditions of use due to quality defects damaged, can be repaired, Free repair; free replacement if the manufacturer confirms that it cannot be repaired; repaired or replaced product, Continue to enjoy the warranty during the remaining warranty period (the shortest not less than 30 days). Purchased by sale The ticket date shall prevail; if the purchase date cannot be determined, the warranty period shall be 13 (13) Monthly calculation.

If you apply for a warranty, please call the product service hotline first and execute it in the manner instructed by us.When applying for warranty, you need to provide an accurate, complete and clearly filled out valid sales invoice.The above guarantee does not apply to the following situations:

1. Exceeding the validity period of the three packs;

 Altering the warranty card and product code does not match the product body;

3. Causes caused by misuse, abuse or improper transportation, use, maintenance or storage Obstacles or damage;

 Failure or damage caused by force majeure (such as earthquake, war, disaster, etc.) or accident Bad;

WARRANTY STATEMENT

5. The zipper and tower buckle are damaged due to excessive force;

6. Disconnection or tearing caused by excessive load;

7. Any damage caused by sharp objects;

8. Products with signs of burning or water immersion;

9. Damage caused by unauthorized disassembly;

10. Aging, discoloration, abrasion, rupture and other losses that occur

during the normal use of the product.

Warranty statement

11. If the original identification label of the product is changed or damaged, this guarantee will become invalid.

The completeness and appearance of the product and accompanying materials are not within the scope of the guarantee. You should Check on the spot and raise objections to any discrepancies.

The above guarantees are all guarantees we make regarding the products,

and are only applicable in mainland China

. Nothing in this document affects consumer rights that cannot be excluded

or restricted under the law

Profit.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) this device may not cause harmful interference, and

(2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.

- Increase the separation between the equipment and receiver.

-Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

-Consult the dealer or an experienced radio/TV technician for help.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.