



Important Product Information Safety Information

 FAILURE TO FOLLOW THESE SAFETY INSTRUCTIONS COULD RESULT IN FIRE, ELECTRIC SHOCK, OR OTHER INJURY OR DAMAGE.

Do not expose your device to liquids. If your device gets wet, carefully unplug the device without getting your hands wet and wait for the device to dry completely before plugging it in again. Do not attempt to dry your device or adapter with an external heat source, such as a microwave oven or a hair dryer. If the device or adapter appear damaged, discontinue use immediately. Use only accessories supplied with the device to power your device. To avoid risk of electric shock, do not touch your device or any wires connected to your device during a lightning storm.

 AVOID PROLONGED LISTENING AT HIGH VOLUME. Prolonged listening of the player at high volume can damage the ear of the user. To prevent possible hearing damage, users should not listen at high volume levels for long periods.

Recycling Your Device Properly

In some areas, the disposal of certain electronic devices is regulated. Make sure you dispose of, or recycle, your device in accordance with your local laws and regulations. For information about recycling your device, go to www._____.com/devicesupport.

Product Specifications

Model Number: C77A68
Electrical Input: 100–240V~, 0.5A, 50/60Hz
Output: 5V = 1.5A max
Temperature Rating: 0–35°C

FOR CANADIAN CUSTOMERS

Innovation, Science and Economic Development Canada (ISED) Compliance

This device contains license-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's license-exempt RSS(s). Operation is subject to the following two conditions: (1) This device may not cause interference; and (2) This device must accept any interference, including interference that may cause undesired operation of the device.

Information regarding exposure to radio frequency energy

This equipment complies with IC RSS-102 RF exposure limits set forth for an uncontrolled environment.

This device for operation in the band 5150-5250 MHz is only for indoor use to reduce the potential for harmful interference to co-channel mobile satellite systems.

This equipment should be installed and operated with a minimum distance of 20 cm between the radiator and your body.

CAN ICES-3(B)/NMB-3(B)

POUR LES CLIENTS CANADIENS

Conformité Innovation Sciences et Développement Économique Canada (ISDE)

L'émetteur/récepteur exempt de licence contenu dans le présent appareil est conforme aux CNR d'Innovation, Sciences et Développement économique Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes :

(1) l'appareil ne doit pas produire de brouillage ; et

(2) l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

Informations concernant l'exposition aux radiofréquences


Cet équipement est conforme aux limites d'exposition aux rayonnements IC établies pour un environnement non contrôlé.

Les appareils fonctionnant dans la bande de 5150 à 5250 MHz sont réservés uniquement à une utilisation à l'intérieur afin de réduire les risques de brouillage préjudiciable aux systèmes de satellites mobiles utilisant les mêmes canaux.

Cet équipement doit être installé et utilisé avec un minimum de 20 cm de distance entre la source de rayonnement et votre corps.

CAN ICES-3(B)/NMB-3(B)

Getting to know your device




1. Download the app

Download and install the latest version of the app from the app store.

2. Plug in your device


Plug your device into an outlet. Your device works best when plugged directly into an unobstructed wall outlet away from large pieces of furniture or appliances. In about a minute, your device will greet you and let you know to complete setup in the app.



3. Set up your device in the app

Open the app and follow the on-screen instructions to set up your device. If you aren't prompted to set up your device after opening the app, just tap the Devices icon in the lower right of the screen to get started.

The app helps you get more out of your device. It's where you set up calling and messaging, and manage music, lists, settings, and news.



For help and troubleshooting, go to Help & Feedback in the Alexa app or visit www._____.com/devicesupport.

For the best experience, set up your device via the app. You can also start the setup process at https://apps._____.com.

4. Things to try with your device

Enjoy your favorite music and audio books

*Set volume to 8.
Resume my audiobook.*

Get news, podcasts, weather, and sports

*Tell me the news.
What is the weekend weather forecast.*

Voice control your smart home

*Turn off the lamp.
Set the temperature to 72 degrees.*

Stay organized and manage your home


*Reorder paper towels.
Set an alarm for 7 AM.*

Some features may require customization in the app, a separate subscription, or an additional smart home compatible device.

For more examples, select Things to Try from the app menu, or visit _____.com

Optional: Connect to a speaker

You can connect your device to a speaker using Bluetooth or 3.5 mm audio cable. If you're using a 3.5 mm cable, your speaker should be at least 6" away. If you're using Bluetooth, go to the Device settings in the app to complete pairing and place your speaker at least 36" away from your device for optimal performance.



Optional: Connect an accessory

You can connect a compatible accessory by plugging the accessory into the USB-A port. In about a minute, your device will discover and automatically connect the accessory. You can also find the accessory on the Devices page of the app to control and create routines.

