



N1 BLUE TOOTH HEADPHONE

Packing List

- blue tooth headphone*1
- user manual*1
- earmuff*2
- micro USB cable*1


Technical specification

Bluetooth Profile	A2DP/AVRCP/HSP/HFP/SBC
RF Range	≤ 10m
Charging Time	1h-2h
Playback Time	≈ 6h-8h
Talk Time	≈ 6h-8h
Battery Capacity	3.7V/130mAh

Indicator Light Introduction

Pairing mode:Blue LED and Red LED flash alternately
 Connected mode:Blue LED flash slowly
 Charging mode:Red LED bum steady
 Charge complete: Blue LED bum steady

Product Buttons Introduction



R Front R Profile

Charging Introduction

- 1.When the Bluetooth headset is connected, if the indicator light turns red, it means that the battery is less than 10%,and the beep will ring.
- 2.The red light will always be on during the charging process of the Bluetooth headset. The blue light is always on after being fully charged.
- 3.Android and Apple can display the remaining battery power in the phone status bar.
- 4.Please use the 5V charger for charging. Unsuitable charger may cause hardware damage and other faults.

Notes on Usage and Operation

- 1.Turn on: Press the 'multifunction' button for 2 seconds when the device is off.
- 2.Turn off: Press the 'multifunction' button for 3 seconds when the device is on.
- 3.Pairing mode: The headphone can automatically entered into the pairing mode when the device is on.

Bluetooth Connection Operation

- 1.Keep the distance between the Bluetooth headset and the phone (or other connected devices) within 1 meter, as close as possible.
- 2.Make sure that the headset is in the off state, press and hold the multi-function button for about 3 seconds until the indicator light flashes red and blue alternately. At this time, the headset enters the pairing state and waits for the connection (if the pairing is not successful within 5 minutes after the power-on,

Bluetooth Connection Operation

- 4.Answer/end call: Press the 'multifunction' button for 1 second while the call coming; Press the 'multifunction' button for 1 second to end the call.
- 5.Reject call: Press the 'multifunction' button for 2 seconds to reject call when the call is ringing.
- 6.Last number redial: Double-click the 'multifunction' button.
- 7.Previous/Next music: Press '+' is for previous music, press '-' is for next music.
- 8.Volume control: Long press '+' is for volume up, long press '-' is for volume down.(When the volume turn into MAX or MIN, you will hear the warning tone)

Points for Attention

- 1.Keep the device dry. Precipitation, humidity, and all types of liquids or moisture can contain minerals that will corrode electronic circuits.
- 2.Do not store the device in hot areas. High temperatures can shorten the life of electronic devices, damage batteries, and warp or melt certain plastics.
- 3.Do not expose the product to direct sunlight for a long time.
- 4.Do not dispose of batteries in a fire as they may explode. Batteries may also explode if damaged.
- 5.Do not attempt to open the device, this product does not contain any

Customer Support

This product warranty period is 12 months, lifetime customer service support

Customer Support

repairable components.
 6.Do not use this product in rain.
 7.If you do not use this product for a long time, please keep it in a dry environment, avoid extreme temperatures and dust and charge your headphones at least once a month for extending battery life.

Customer Support

This equipment is provided with a one-year valid product warranty service from the date of purchase. Please pay attention to the NFHIFI WeChat public account for details.

According to the national "Three Guarantees" regulations, you have the following after-sale rights during the warranty period under the condition of complete product appearance and packaging.

- 1.If the product quality problem occurs within 7 days, please return the product to the place of purchase or the address specified by our company. With the valid certificate, we will refund the payment for the product you paid.
- 2.Product quality problems occur within 90 days, you can go to the purchase address or our designated location to replace the hardware products, or our designated repair outlets for warranty, the replacement hardware warranty period is the number of days remaining in the warranty period.
- 3.Product quality problems occur within one year, you can go to our designated repair outlets for warranty.

Warranty limit

This Limited Warranty does not cover faults or damage caused by the following reasons.

- 1.Accidents, misuse, improper operation or any unauthorized repair, modification or disassembly.
- 2.Improper operation or repair, connected to an inappropriate power supply in violation of product instructions during use.
- 3.Use consumables not provided by our company (such as spare batteries), except when using the law to stop such restrictions.
- 4.Damage caused by other force majeure factors.

FCC Warning

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.