

Item	Description
Model	YGA03C17-8.5W-A19-2700K/6500K-Smart
Function	On/Off/Dimmable/ CCT adjustable / Bluetooth control
Power	8.5W
Voltage (v)	120
Power Factor (w)	0.5
Luminous Flux (lm)	800
CCT(k)	2700K/6500K
CRI	80
Beam Angle	200
Diameter (mm)	φ60
Life (h)	10000
Control Distance(m)	15

User Guide

1. Install the smart bulb into a power OFF light socket.
2. Download the Energetic Lighting App from the APP Store or from Google Play. Create an account and enter into the APP.
3. Turn on the Bluetooth on the phone. Tap “+” in the top-right corner of the app and then select “search device”.
4. Power up the smart bulb.
5. The bulb will appear in the app. Tap the icon and wait until it is added successfully..
6. You can turn on or off the bulb, and adjust its brightness and CCT using the app.
7. If the bulb is switched off, it cannot be controlled by app.

FCC Warning

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
—Reorient or relocate the receiving antenna.

- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

ISED RSS warning

This device complies with Innovation, Science and Economic Development Canada Compliance licence-exempt RSS standard (s). Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

Le présent appareil est conforme aux CNR d'Innovation, Sciences et Développement économique ISED applicables aux appareils radio exempts de licence.

L'exploitation est autorisée aux deux conditions suivantes:

- (1) l'appareil ne doit pas produire de brouillage, et*
- (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.*

FCC/ ISED Radiation Exposure Statement

This equipment complies with FCC/ISED radiation exposure limits set forth for an uncontrolled environment .

This transmitter must not be co - located or operating in conjunction with any other antenna or transmitter.

This equipment should be installed and operated with minimum distance 20cm between the radiator &you body.

Cet équipement est conforme à la radiation FCC / ISED limites d'exposition établies pour un environnement non contrôlé.

Cet émetteur ne doit pas être situé ni utilisé conjointement avec une autre antenne ou un autre émetteur.

Cet équipement doit être installé et utilisé à une distance minimale de 20 cm entre le radiateur et votre corps.