

11G_Ant1_2412_0~Reference



11G_Ant1_2412_30~1000



11G_Ant1_2412_1000~26500



11G_Ant1_2437_0~Reference



11G_Ant1_2437_30~1000



11G_Ant1_2437_1000~26500



11G_Ant1_2462_0~Reference



11G_Ant1_2462_30~1000



11G_Ant1_2462_1000~26500



11N20SISO_Ant1_2412_0~Reference



11N20SISO_Ant1_2412_30~1000



11N20SISO_Ant1_2412_1000~26500



11N20SISO_Ant1_2437_0~Reference



11N20SISO_Ant1_2437_30~1000



11N20SISO_Ant1_2437_1000~26500



11N20SISO_Ant1_2462_0~Reference



11N20SISO_Ant1_2462_30~1000



11N20SISO_Ant1_2462_1000~26500

10.7. Appendix G: Duty Cycle

10.7.1. Test Result

Test Mode	On Time (msec)	Period (msec)	Duty Cycle x (Linear)	Duty Cycle (%)	Duty Cycle Correction Factor (dB)	1/T Minimum VBW (kHz)	Final setting For VBW (kHz)
11B	16.38	16.43	0.9970	99.70	0.01	0.06	0.01
11G	2.71	2.76	0.9819	98.19	0.08	0.37	0.5
11N20SISO	2.52	2.57	0.9805	98.05	0.09	0.40	0.5

Note:
Duty Cycle Correction Factor=10log (1/x).
Where: x is Duty Cycle (Linear)
Where: T is On Time
If that calculated VBW is not available on the analyzer then the next higher value should be used.

10.7.2. Test Graphs



11B_Ant1_2437



11G_Ant1_2437



11N20SISO_Ant1_2437

END OF REPORT