

2.0 Channel Soundbar

Model: HD-007DB

User Manual

Thank you for purchasing this Sound Bar, Please read this instruction manual carefully before using this product to ensure proper use. Keep this manual in a safe place for future reference.

A compact yet powerful Bluetooth soundbar with sleek looks and excellent audio response. 6 inbuilt speakers and 2 bass tube provide clarity across a broad frequency range, with crisp highs and deep bass that belie the unit's size. An integral USB port enables playback of MP3/WAV files directly from compatible media, with further flexible input options including Aux, HDMI(ARC), Optical and Bluetooth. A convenient and cost-effective TV audio upgrade that doesn't compromise on performance.

- Slender and stylish metallic grey design
- 6 speakers for crisp, clear sound with deep bass

- 2.0 channel amplifier with 3 EQ presets
- Versatile input options to support a range of devices
- USB port for MP3 and WAV media playback
- Remote control and Aux cable included

Matters Need Attention

1. Don't put this product under high temperature wet environment and it will be worse when it is in the rain or crash strongly.
2. To reduce the risk of electronic shock or fire, do not remove the cabinet cover simply contact a service professional.
3. In the rare occurrence of malfunction, do not attempt to repair the unit on your own. Contact a certified service professional for a proper diagnosis and repair.
4. If fragments or liquids fall into device box, please cut off the power right away. And it can be used only after professional staff checks it.
5. Don't install the unit in or near a place where it may come in contact with rain, moisture or other liquids.

Technical Specifications and Features

Power output: 60W

Speaker drivers: 2.25" speakers * 4 + Tweeter * 2

Bluetooth version: 5.0+EDR

Bluetooth range: Up to 10m

Connections: HDMI(ARC), OPTICAL, USB, AUX (3.5mm)

Power supply: 100-240V 50/60Hz

Dimensions: Soundbar 935 x 65 x92mm

Accessories:


User manual x 1

Remote control x 1

Power cable x 1

Aux-in cable x 1

Connections



1.HDMI(ARC): Use to connect compatible devices using a HDMI cable (not provided).

2.OPTICAL IN: Use to connect compatible devices using an optical cable (not provided).

3. USB IN: Use to connect a flash drive for direct MP3/WAV playback (FAT32 format and 64GB max).

4. AUX IN: Use to connect compatible devices using the 3.5mm – 3.5mm stereo jack cable (provided).

LED display

1. Red LED: Standby mode

2. bt: Bluetooth mode

3. USB: USB media mode


4. AUX: Auxiliary input mode

5. OPT: Optical mode







6. ARC: HDMI(ARC)mode


Remote Control

Control panel keys



bomaker

	Short press to turn on, long press to turn off	MUSIC	Music Mode/EQ 1
	Mute/ Recover the Volume	MOVIE	Movie Mode/EQ 2
BT	Go to BT Mode	NEWS/Game	News mode is displayed as EQ3/ Game mode is displayed as EQ4
HDMI	Go to HDMI Mode	OPTICAL	Go to Optical Mode
DYNAMIC	To enhance the dynamic effects of different EQ modes such as Music/Movie/News/Games/3D, suitable for scenes of needing more powerful sound effects.		
Hi-Fi	To adjust the sound effects on different EQ Modes such as Music/Movie/News/Games/3D to get clearer sound, suitable for some quiet scenes such as dialogue.		
AUX/USB	Go to Aux/USB Mode	BASS+	Increase the Bass
+	Volume Up	BASS-	Decrease the Bass
-	Volume Down	3D	3D Surround sound on/off, can only be turned on in movie mode
	Previous Track		Next Track
	Play/Pause	 /LED OFF	Short press button for Single loop or Full loop in USB mode /Short press to turn on/off the LED indicator in standby mode.



1	Power on/off button
2	Short Press to change the input mode, LED screen show current mode.
3	Long press to adjust the volume, when adjusting, LED screen will showed the number Short press to prev song or next song under BT and USB mode

Input Functions

- **Power on/off:** Press the Power on/off button on the remote control or soundbar control panel to turn the unit on and off.
- **HDMI(ARC):** Connect an HDMI ARC compatible device to the HDMI(ARC) port on the soundbar using a HDMI cable (not supplied). Select HDMI(ARC) mode either by pressing the HDMI(ARC) button on your remote control or repeatedly pressing the MODE button on the soundbar control panel until ARC is displayed on the LED display. Ensure HDMI ARC is selected as the TV's audio output, then adjust the volume of soundbar using the Volume up and Volume down buttons on the remote control or soundbar control panel.
- **AUX in:** Connect a compatible device using the 3.5mm – 3.5mm stereo jack cable. Select AUX mode either by pressing the AUX button on your remote control or repeatedly pressing the MODE button on the soundbar control panel until AUX is displayed on the LED display. Ensure the connected device is producing an audio signal, then adjust the volume of soundbar using the Volume up and Volume down buttons on the remote control or soundbar control panel.
- **Optical in:** Connect a compatible device to the OPTICAL input on the soundbar using a digital optical cable (not supplied). Select OPT mode either by pressing the OPT button on your remote control or repeatedly pressing the MODE button on the

soundbar control panel until OPT is displayed on the LED display. Ensure Optical SPDIF is selected as the TV's audio output, then adjust the volume of the soundbar using the Volume up and Volume down buttons on the remote control or soundbar control panel.

- **Bluetooth:** Press the BT button on the remote control or repeatedly pressing the MODE button on the soundbar control panel until bt is shown on the LED display. The LED display will flash to indicate that the soundbar is in Bluetooth pairing mode. Ensure that the device you wish to connect is also in pairing mode and search for "Odine V" in its device list. When the two devices are paired, the LED display on the soundbar will stop flashing and remain constant. (The soundbar will now automatically re-pair with this device whenever it is within range and has Bluetooth turned on.)

- **USB media mode:** The soundbar is compatible with USB flash drives of up to 64GB(Fat32 format) in size and can play MP3 and WAV audio files directly. Simply insert a compatible drive into the USB port on the back of the soundbar and the unit will automatically switch to USB mode and play the first compatible track.

USB repeat mode (also accessed via the remote control) enables single track repeat (ONE), all track repeat (ALL)

The media player also has a memory function that will recall and continue from the last-played point when a USB flash drive that has previously been used with the soundbar is reinserted.

FCC WARNING

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different

from that to which the receiver is connected.

- Consult the dealer or an experienced radio/TV technician for help.

To maintain compliance with FCC's RF Exposure guidelines, This equipment should be installed and operated with minimum distance between 20cm the radiator your body: Use only the supplied antenna.