

# ***DUO***

***hym***  
originals

*DUOSmart Turntable Audio Station*

Instruction

## Safety Instructions

- 1 Read these instructions.
- 2 Keep these instructions.
- 3 Read all warnings.
- 4 Follow all instructions.
- 5 Do not use this apparatus near water.
- 6 Clean only with a dry cloth.
- 7 Do not block any ventilation openings. Install in accordance with the manufacturer's instructions.
- 8 Do not install near any heat sources such as radiators, heat registers, stoves or other apparatus that produce heat.
- 9 Protect the power cord from being walked on or pinched, particularly at plugs, convenience receptacles and the point where they exit from the apparatus.
- 10 Only use attachments/accessories specified by the manufacturer.
- 11 Refer all servicing to qualified service personnel. Servicing is required when the apparatus has been damaged in any way, spilled or objects have fallen into the apparatus, the apparatus has been exposed to rain or moisture, does not operate normally, or has been dropped.
- 12 Unplug this apparatus during lightning storms or when unused for long periods of time.
- 13 To completely disconnect this apparatus from the AC Mains, disconnect the power supply cord plug from the AC receptacle.
- 14 Do not place naked flame sources, such as lighted candles, on the apparatus.

### Warning


To reduce the risk of fire or electric shock, do not expose this apparatus to rain or moisture. The apparatus shall not be exposed to dripping or splashing and that objects filled with liquids, such as vases, shall not be placed on the apparatus.

### Notes



This product has been tested with level adjustment before leaving the factory and it is recommended to be placed on the leveled table for usage.

Only available for an altitude no more than 2,000 meters. Only available for non-tropical climatic conditions.


# Part List




# Interface Guide




# Part Description






① Plug in the power line, turn the Speed Switch to the Standby mode


② Press the Power ON/OFF button for 3 seconds on the Bluetooth Speaker, the speaker will pair the turntable automatically



③ Move the Tonearm from the holder gently, and take out the holder



④ Put the vinyl record on the turntable, take off the stylus cover, put the holder on the vinyl record gently




⑤ Turn the Speed Switch to proper speed (33 rpm or 45 rpm)


⑥ Put the Tonearm on the vinyl edge

⑦ Start playing


If pairing failed, press the bluetooth pairing button on the turntable for 3 seconds




- ① Turn the Speed Switch to Standby



- ② After the Vinyl stops moving, move the tonearm to the tonearm stand gently, and move the holder from the platter gently



- ③ After the vinyl is removed, put the holder back to the slot on the turntable




- ④ Reset the tonearm on the holder

## 2



### Bluetooth Mode




- ① After the turntable is switched off, press the bluetooth button on the speaker for 3 seconds
- ② Turn on the bluetooth on the smartphone
- ③ Choose HYM-DUO to pairing
- ④ Pairing completed
- ⑤ Choose music to play

If pairing failed, press the bluetooth pairing button on the speaker for 3 seconds


## 3



### Stereo Pairing Mode



A Speaker




B Speaker

- ① After the turntable is switched off, press the bluetooth button on the speaker
- ② Press the Bluetooth pairing button of both A and B Bluetooth speakers for 3s
- ③ After 2 speakers connected successfully, Speaker A willactively re-connect the smartphone or the turntable
- ④ Pairing completed
- ⑤ Choose music to play

If pairing failed, press the bluetooth pairing button on the speaker for 3 seconds

# 4


## Turntable With Other Bluetooth Device




- ① Plug in the power line, Turn the speed button to standby mode  
Light color will be flash white
- ② Turn on the bluetooth device, waiting for connection
- ③ Pairing completed  
Light color will be solid white
- ④ Start playing vinyl

# 5

## Light Indication



Status	Light color on turntable
Bluetooth Pairing	Flashing white
Pairing completed	Solid white



Status	Light color on speaker
Bluetooth Pairing	Flashing green
2-Speaker pairing	Breathing green
Pairing completed	Solid green
Low battery	Solid orange
Charging	Breathing white

\*5 hours needed for full charge



FCC Warning:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference

received, including interference that may cause undesired operation.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment.

## ISED Statement

- English: This device complies with Industry Canada license-exempt RSS standard(s). Operation is subject to the following two conditions: (1) This device may not cause interference, and (2) This device must accept any interference, including interference that may cause undesired operation of the device.

The digital apparatus complies with Canadian CAN ICES-3 (B)/NMB-3(B).

- French: Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes: (1) l'appareil ne doit pas produire de brouillage, et (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

l'appareil numérique du ciem conforme canadien peut - 3 (b) / nmb - 3 (b).

This device meets the exemption from the routine evaluation limits in section 2.5 of RSS 102 and compliance with RSS 102 RF exposure, users can obtain Canadian information on RF exposure and compliance.

cet appareil est conforme à l'exemption des limites d'évaluation courante dans la section 2.5 du cnr - 102 et conformité avec rss 102 de l'exposition aux rf, les utilisateurs peuvent obtenir des données canadiennes sur l'exposition aux champs rf et la conformité.

This equipment complies with Canada radiation exposure limits set forth for an uncontrolled environment.

# **DUO**

**hym**  
*originals*

*DUOSmart Turntable Audio Station*

*Designed by HYM*