

Model# Phantom 3
rev 04-24

Bushnell
GOLF

QUICK START GUIDE



PHANTOM 3 SLOPE

Golf GPS Rangefinder

Scan the code to
download the Bushnell
Golf Mobile app and
register your Phantom 3
Golf GPS.



Android and Google Play are registered trademarks of Google Inc. in the United States and other countries. iPhone and Apple Store are trademarks of Apple Inc., registered in the U.S. and other countries. Other names may be trademarks of their respective owners.



Controls/Parts and Play Golf Screen Guide

1. POWER/BACK/LOCK BUTTON: see below for further explanation
2. FLAG - Indicates pin has been moved in Greenview
3. BLUETOOTH - Indicates in the unit is connected via Bluetooth
4. BATTERY LIFE INDICATOR
5. CENTER DISTANCE - Distance to center of the green (or pin, if it has moved)
6. FRONT DISTANCE - Distance to front of the green.
7. BACK DISTANCE - Distance to back of the green
8. HOLE - Current hole number
9. PAR - Par for the current hole
10. SCORE - User's current total score for the round
11. SLOPE INDICATOR - Illustrates the calibration status for slope feature (see below for further explanation)
12. PREVIOUS HOLE
13. HOME BUTTON/FAVORITE: Default is no function (To define favorite: Settings > Golf Settings > Home Button)
14. NEXT HOLE
15. USB-C PORT - Connect to charge unit


Quick Start Operation Guide


1. **Power On:** Press and hold the Power button to turn on the device. The Home Screen is displayed.
2. To start the game, tap Play Golf on the Home Screen. With its efficient GPS connectivity, the device will select the course nearest to your location and even the hole if you are on a teebox or green. To change courses, navigate to Settings > Course Select. *The device's GPS connection will be even faster when you are outside, with a clear view of the sky.*
3. Navigate to functions from Front/Center/Back: (Power button navigates back to Front/Center/Back Screen)
 - Greenview - Swipe Left
 - Hazards and Layup points - Swipe Right
 - Shot Distance Calculator - Swipe Down
 - Menu - Swipe Up (Round Summary, Clock, Settings, Exit Game)
4. **Power Off:** Press and hold the Power button for 3 seconds.

**From Front/Center/Back Screen, disregard Lock Screen, keep holding button.*

Features

Slope Mode (11):

 - Indicates unit is calibrated and displaying slope compensated distances.

 - Indicates unit is not calibrated and is displaying non slope compensated distances.

- To display the Straight-Line Distance in Slope Mode, tap the Center Distance. Unit will display the Straight-Line Distance for 3 seconds, then return to Slope Compensated Distances.

**Blinking Slope Icon - Still receiving slope compensated distances but need to update calibration for more accurate distances.*

**Calibrate unit by taking it to a Teebox or Green.*

Screen Lock:

To lock the screen while playing a round, press and hold the Power button until the Lock icon appears. Repeat the process to Unlock.

For a full user manual, operating details, product use questions and warranty/repair information, please visit:
www.BushnellGolf.com/support

⚠ WARNING: Bite feature included with device contains a Neodymium magnet. Magnets could affect the functioning of pacemakers and implanted heart defibrillators. If you use these devices, keep sufficient distance from magnet. Warn others who wear these devices from getting too close to magnets.

- Magnet may lose part of its adhesive force permanently if exposed to temperatures above 175° F (80° C).
- Magnets produce far-reaching, strong magnetic field. They could damage TVs and laptops, computer hard drives, credit and ATM cards, data storage media, mechanical watches, hearing aids and speakers. Keep unit away from devices and objects that could be damaged by strong magnetic fields.

⚠ WARNING: Do not attempt to open the Phantom 3. The Phantom 3 contains a rechargeable lithium ion battery. Risk of explosion if battery is replaced with incorrect type.

- Do not attempt to open, disassemble or service the internal battery. The battery must be replaced by a qualified technician.
- Do not crush, puncture or short the battery's external contacts. Do not expose to temperatures above 140° F (60° C).
- Do not charge the battery if ambient temperature is over 113° F (45° C)
- Properly recycle or dispose of the battery. Do not dispose in fire or water.

FCC Statement

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Shielded interface cable must be used with the equipment in order to comply with the limits for a digital device pursuant to Subpart B of Part 15 of FCC Rules. Specifications and designs are subject to change without any notice or obligation on the part of the manufacturer.



214-240066 CMIIT ID: 24J9988G7087



80950/SDPPI/2022

13902

Disposal of Electric and Electronic Equipment (Applicable in the EU and other European countries with separate collection systems)

This equipment contains electric and/or electronic parts and must therefore not be disposed of as normal household waste. Instead, it should be disposed at the respective collection points for recycling provided by the communities. For you, this is free of charge. If the equipment contains exchangeable (rechargeable) batteries, these too must be removed before and, if necessary, in turn be disposed of according to the relevant regulations (see also the respective comments in this unit's instructions). Further information about the subject is available at your community administration, your local waste collection company, or in the store where you purchased this equipment.



Industry Canada Statement

This device complies with ISED's license-exempt RSSs. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Radiation Exposure Statement:

This device complies with the Industry Canada portable RF exposure limit set forth for an uncontrolled environment and is safe for the intended operation as described in this manual. Further RF exposure reduction can be achieved if the product can be kept as far as possible from the user's body or if the device is set to a lower output power if such function is available.

Industry Canada Statement

Le présent appareil est conforme aux CNR d'ISED applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes: (1) le dispositif ne doit pas produire de brouillard préjudiciable, et (2) ce dispositif doit accepter tout brouillard reçu, y compris un brouillard susceptible de provoquer un fonctionnement indésirable.

Déclaration d'exposition aux radiations:

Le produit est conforme aux limites d'exposition pour les appareils portables RF pour les États-Unis et le Canada établies pour un environnement non contrôlé. Le produit est sûr pour un fonctionnement tel que décrit dans ce manuel. La réduction aux expositions RF peut être augmentée si l'appareil peut être conservé aussi loin que possible du corps de l'utilisateur ou que le dispositif est réglé sur la puissance de sortie la plus faible si une telle fonction est disponible.

