

When the earphone is under charging, red light will stay on and go out when full charged

answer the call, touch any earphone to hang up during the call. When a call comes in,

\*Double-touch: Left earshone ->skip back, right earshone ->skip forward

5.Phone call mode

long press 25: reject the call.

6. How to use the earphone? Single-touch left or right earphone : Play/Pause, AnswerHang up

100

Open case, the earphone will power on automatically. Or manually press the button within 5 seconds, the blue light flashes 2 times, then redikblue light flashing to powe

(if the charging box standby for a long time it will default without power, but

then it will power on)

the earthcres of a with with power, just press the earthcres around 3 seconds.

The earphone will power off when putting it into the charging case with lid closed,

( if earphone not connected, it will automatically power off after 3 minutes)

Or manually cross the "nower" button for 5 seconds to turn it off.

-0

A. Charging Contactor B. Touching Area

D. Digital LED Display

User Manual



to the effect of the environment on the product. Nake sure the connection is smooth recommend a distance between these within 10 meters.

If the explane field is connect or with poorly connection, please do not dismartle it or the accessors privately. Otherwise no warranty, S. When charalying the cospitions, please use the standard car charger or the charger needfort for an emproper.

specified by our company. 6. To ensure the normal use of the earphones, please make sure they are fully changed.

During normal use of this product, if the product has non-artificially damage, parformance failure. From the date of the purchase, consummers onjoy a fire warranty period with 12 thorotica. In one of the following circumstances, comsummers cannot enjoy fire fires

Warranty Service:

User address (including zip code)

Seller address (including zip code)

Invoice number

Seller phone no.

Certificate

Product number

Stand-by time: 120 days     Talk time: 2 hours     Charging time: 60 mins	Charging voltage: DC SV Transmission distance: 10m -15 m Frequency Response: 20-20000 Hz Charging case battery: 300 mAh Music playine: 4.5 hours	0 Hz	"Sajakouch: Lift augstens — vallens dann sigt eingetens — vollens up "Lang press jelt or right engebren 2 secondes Activides Sist	• Do not us the device in his buy, compact or our impacts fall to kneed fallow for a stand code on the device. As purpose to the compact page to device our device of the code of the code of the device of the code of the	as towards wash, Propose disposal of the latter, may use all to latter to use. Changes solidy,  if their change is a disposition, the govern codes should be included more the choice and  without change is consistent or may be consistent to the choice of the choice and the concession, and support repeding operation.	1. Antickly distrings.     5 Exceeds the environity profest.     3. Carent growths wild proof of professes.     3. Carent growths wild proof of professes.     4. The base to see an extensive the product in accordance with the instructions.     5. Unusualizated, distrinsive or report the products principle or product was soasked.     5. Other distrings caused by brown registers.		Inspector  Date  Packing List  *Wireless carphones #User manual *USB charging cable *Charging case		
	1	2	3	4	5			7		
					_					
						深圳恩乐实业有限公司产品说明书				
						物料名称	TW13耳机说明书S	5-1.2	物料号码	307-BC-0863
						工 艺	彩色印刷,风琴技	f页 E	期	2020-08-06
						材 质	材质: 105g铜版纸(5	双铜) 试	<b>计</b>	王金松
						规 格	480mm*80mm	fi fi	1 认	周雄

attery leakage, excessive, fine or explanion. Do not drop, crush or puncture the battery. It can cause internal short circuits and

Please dispose batteries in accordance with local regulations. Do not dispose as household waste, improper disposal of the battery may cause the batter

model all occurs or personal model all occus, such as possessions, sucher implement personal personal personal model all occurs of the personal personal personal model personal person

cause accidents.

Operating environment

On not use the device in clusty, sharp, compact or near magnetic fields to avoid failure.

## **FCC Warning Statement**

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- - Reorient or relocate the receiving antenna.
- - Increase the separation between the equipment and receiver.
- - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- - Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and

(2) this device must accept any interference received, including interference that may cause undesired operation.

The device has been evaluated to meet general RF exposure requirement.