Armor 15 uBuds Inside-蓝牙耳机说明书


成品尺寸: 70x113(mm)

材质: 128g铜板双面印过哑胶

Armor 15 uBuds Inside

USER MANUAL

uleFone



Charging Indications

(1) Charging. Put the earbuds in the charging case (on the top of Armor 15) to charge, when the earbuds are charging, the red light is always on and the status bar at the top of Armor 15 will display the earbuds battery icon and charging prompt; when the earbuds are fully charged, the indicated light goes out and the battery prompt disappear.

(2) Low Power Prompt. When the earbuds battery voltage is lower than 3.55V, there will be a "Low Battery" warning tone every minute.

(1) Boot Method: Pick up two earbuds from the charging case and they will automatically turn on. (There is a "Power ON" tone)

(2) Shutdown Method:

① Put the earbuds into the charging case, the earbuds is turned off. (There is a "Power Off" tone)

② After turning on or disconnecting the Bluetooth, if there is no operation, the earbuds will automatically shut down after about 3 minutes.

3 Low Power Shutdown:

When the earbuds battery voltage is lower than 3.2V, the earbuds will automatically shut down.

Pairing and Connection

Pick up two earbuds from the charging case to flash between a red and blue light (When TWS is not paired), and the two earbuds are automatically paired (There is a "TWS Pair Successful" tone); when the TWS pair is successful the blue light of the left and right earbuds flash quickly.

Fast Pairing

When the Bluetooth of the phone is turned on, take out two earbuds from the charging case, and the phone will automatically pop up a quick pairing prompt: follow the prompts to complete the pairing and connection to the phone. (with a "Bluetooth Connection Is Successful" tone and the indicated

Note: Only after connecting for the first time or clearing the Bluetooth connection record, a pairing prompt box will pop up. Subsequent connections will be automatically reconnected without a pairing prompt

(1) Connect Manually

Find the Bluetooth menu in the Settings and turn Bluetooth on; search for Bluetooth devices and select "uBuds Inside" to pair, (with a "Bluetooth Connection Is Successful* tone and the indicated light goes out.)

(2) Reconnect Automatically

When the earbuds is on and paired with TWS successfully (with a "TWS Pair Successful* tone and the blue light of the left and right earbuds flash quickly) it will enter the reconnection mode within 5 seconds and reconnect to the latest paired device. (with a "Bluetooth Connection Is Successful" tone and all the indicated light goes out)

The earbuds can be too far from the phone to cause disconnection, if the earbuds is back to the working area in 3 minutes the connection will be recovered; or you need to reconnect it manually if over 3 minutes.

Bluetooth Disconnected

(1) Disconnect for Great Distance

The earbuds and the mobile phone are disconnected for the distance is too far. If the earbuds can not be back to the working area within 3 minutes, it will disconnect the Bluetooth and turn off.

(2) Disconnect Manually

Find the Bluetooth menu in the Settings; search for paired device and click " uBuds Inside" to disconnect or delete device.

The earbuds supports single ear mode; taking out a single earbud from the case to automatically reconnect to the latest paired device; if there is no paired device, you can manually pair it with Bluetooth.

Functions and Operations

When the earbuds is in the pairing state, after connecting with the mobile phone, when there is an incoming call, there will be a ringtone reminder of the incoming call.

(1) Answer Incoming Calls

Double click the left or right earbud switch button to answer the call. (In single ear mode, operate in the same way)

(2) Hang up the Phone

During the conversation with the other party, if you want to end the call, double click the left or right earbud switch button to hang up the call. (In single ear mode, operate in the same way)

Press and hold the left earbud or right earbud switch button for 2 second just operate in the same way)

Music/Standby Mode

When the earbuds is in the pairing state, after connecting with the mobile phone, select the APP playback software you need to start, then double click

the left or right earbud switch button to start playing music; double click the left or right earbud switch button again to pause the music playback. (In single ear mode, operate in the same way)

(2) Cut Songs (up and down songs)

phone, in the process of playing music, at this time triple-click the left or right earbud switch button, the music can switch to the next song; quadruple-click the left or right earbud switch button, the music can switch

When the earbuds is successfully paired and connected to the mobile on the voice assistant (There is a "Di" prompt tone), and press and hold the left or right earbud button for 5 second again to turn off the voice assistant (There is a "Di" prompt tone): it supports Siri and Google Assistant.

Operation Exception Handling Method

(1) There is no sound in a certain earbud due to improper operation or long-time shielding of the earbud signal. Please try to move to the range where the signal can be received to restore normal.

(2) For failures caused by unknown causes, turn off the earbuds and then turn it on

(3) If you change a single product or misuse it, causing the left and right earbuds to be disconnected, pair the left and right earbuds again.

(4) If there is no sound when listening to music after the earbuds is connected to the mobile phone, please go to the Bluetooth settings of the mobile phone and find the name of the connected earbuds (uBuds Inside). When the connection is displayed, click the earbuds name again,

(5) If the two earbuds have been paired and connected to the mobile phone, there is no sound from the earbud after answering the call. You need to check the audio output of the mobile phone and select the Bluetooth pairing name (uBuds Inside) corresponding to the earbud before proceeding Bluetooth call.

Thank you for using this product, we wish you a happy life.

FCC Caution: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two

(1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This device and its antenna(s) must not be co-located or operating in conjunction with any other

MoTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.

- Increase the separation between the equipment and receiver.

- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

Consult the dealer or an experienced radio/TV technician for help. The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure ondition without restriction

F© C € RoHS 🕱