


10.2 Test Graphs

Note: Not found obvious spikes or see marked spikes on plots and listed emissions records.



Frequency (MHz)	Level (dB μ V)	Limit (dB μ V)	Transd. (dB)	Margin (dB)	Line	PE
0.181476	42.35	64.42	9.7	22.07	N	FLO
0.217162	42.36	63.09	9.7	20.73	L1	FLO
0.368676	40.60	58.53	9.7	17.93	N	FLO
0.522495	41.09	56.00	9.7	14.91	N	FLO
0.587625	41.65	56.00	9.7	14.35	L1	FLO
0.787110	41.67	56.00	9.7	14.33	N	FLO

Note:

1, Level =Reading level by receiver + Transd (Antenna factor + cable loss – preamplifier gain)

The reading level is calculated by software which is not shown in the sheet.

2, Margin=Limit - Level

END