

CARD Reader/Encoder

E3

User Manual

CARD Reader/Encoder E3

Model :	E3
Dimensions :	70mm x 70mm x 26mm
Power interface :	Type-C USB
Power input :	5V/500mA
Radio frequency:	13.56Mhz
Support card type:	MiFare S50

Light/sound status



Light:


- Green light indicates: Card Encoder Mode
- Blue light indicates: Card Reader Mode

Sound:

- 🔊 One short Beep indicates successful operation

Steps:

- 1 Connect the USB cable with PC
- 2 Plug the USB into the card encoder



- 3 Follow the instructions of the software to use the Encoder

Limited Warranty

1. For any defect in material and/or workmanship, the original purchaser of the product can:
 - 1) Return or ask for a replacement within 7 days from the date of the Invoice.
 - 2) Ask for a replacement within 15 days from the date of the Invoice.
 - 3) Can ask for a free repair in 365 days from the date of the Invoice.
2. This warranty does not cover defects caused by modification, alteration, misuse or physical abuse of the product.

Disclaimer

We continuously optimize products as new technologies and features are developed. For this reason, we reserve the right to make alterations to the products without prior notice.

FCC Warning Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- - Reorient or relocate the receiving antenna.
- - Increase the separation between the equipment and receiver.
- - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- - Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.