

# Portable Bluetooth Speaker



## NT-B803 Instruction Manual

Please read all of the instructions carefully and retain for future reference

### Safety Instructions

1

1. When using electrical units , basic safety precautions should always be followed .
2. Children aged from 8 years and people with reduced physical , sensory or mental capabilities or lack of experience and knowledge can use this unit , only if they have been given supervision or instruction concerning use of the unit in a safe way and understand the hazards involved .
3. Children should be supervised to ensure that they do not play with unit .
4. Unless they are older than 8 and supervised , children should not perform cleaning or user maintenance .
5. This unit is not a toy .
6. This unit contains no user serviceable parts , if the unit and any of its accessories are malfunctioning or it has been dropped or damaged , only a qualified electrician should carry out repairs , improper repairs may place the user at risk of harm .
7. Keep the unit out of reach of children .
8. Keep the unit away from heat or sharp edges that could cause damage .
9. Keep the unit away from heat sources , direct sunlight , humidity , water and any other liquid .
10. Keep the unit free from dust lint etc .
11. Do not immerse the unit in water or any other liquid .
12. Do not operate the unit if it has been expose to water , moisture or any other liquid to prevent against electric shock , explosion and / or injury to yourself and damage to the unit .
13. Do not use the unit for anything other than its intended use .
14. Do not store the unit in direct sunlight or in high humidity conditions .
15. Do not put objects into any of the openings .
16. Do not play music at excessive volume levels as damage to hearing and / or the equipment may occur . It is imperative to unplug the adaptor after the unit has been used , before it is cleaned and whilst being repaired .
17. To prevent possible hearing damage , do not listen at high volume levels for long periods of time .
18. Warning : Keep the unit away from flammable materials .

### Specifications

2

Power Supply :	DC 5V
Output Power :	10W
Driver Unit :	2.5"4Ω*2
Bluetooth Version :	v5.0
Storage class:	Max Size 64Gb
FM Frequency Range :	87.5-108 MHz
AM Frequency Range :	530-1600 KHz
Frequency Response :	90Hz - 18 KHz
S/N Ratio :	≥ 65dB
Rechargeable Battery :	Lithium 3.7V 3000mAh
Product Size :	W227*H136*D126 mm

### Getting Started

3

1. Remove the unit from the box .
2. Remove any packaging from the unit .
3. Place the packaging inside the box and either store or dispose of safety


### In The Box

4

Bluetooth Speaker	*1
USB Charging Cable	*1
3.5 mm Aux in cable	*1
Instruction Manual	*1

### Description of Parts

5



- |                                      |                      |
|--------------------------------------|----------------------|
| ① MODE                               | ② EQ (Extra Bass)    |
| ③ BT                                 | ④ Prev               |
| ⑤ Play / Pause                       | ⑥ Next               |
| ⑦ Radio Tuner                        | ⑧ Function Switch    |
| ⑨ Power Switch / Volume Control Dial | ⑩ Antenna            |
| ⑪ Aux in                             | ⑫ Mic Receiver       |
| ⑬ Aux Out / Earbud Jack              | ⑭ USB Slot           |
| ⑮ TF Slot                            | ⑯ Charging Indicator |
| ⑰ DC Charging Input                  |                      |

### Instructions for Use

6

#### Bluetooth Operation

1. Turn on the power switch, turn the "Function Switch" to Music, then go to BT mode directly.
2. Searching for pairing name "NT-B803" to connect with device, there is a tone when connected successfully. Music is ready to play after paired .
3. During the play, turning the volume control switch to adjust the volume.
4. In Bluetooth mode, short press "Play/Pause" to answer the incoming call or end the calling;
5. Press " BT " button to disconnect Bluetooth connection , and press again to connect for the disconnected device.

#### USB/TF Operation

1. Insert USB/TF, speaker will play the music directly.
  2. Press " Play/Pause " button then pause or play the music .
  3. During the playback , turning the volume control switch to adjust the volume .
- \*\*\* Please don't take out USB/TF card while playing , otherwise , USB/TF card will be damaged \*\*\*

#### Aux In Operation

1. Press " Mode " button to AUX-IN mode .
2. Insert AUX-IN cable and connect to your device to play music .
3. Press " Play/Pause " button to mute for the music .

#### Radio Operation

1. Turning the Function Switch to FM or AM mode .
2. Adjust the Radio Tuner to locate the FM or AM channel .
3. Pull out the FM antenna and adjust position for better receiving .
4. Press " Play/Pause " button to mute for the radio .

### Instructions for Use

7

#### EQ (Extra Bass)

1. Under the Music MODE , press EQ button to enhance the bass performance of music , press again to cancel the effect .

#### Supplement:

1. Mode Switch Sequence: BT-->TF-->USB-->AUX IN

#### FCC Caution.

§ 15.19 Labelling requirements.  
This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

§ 15.21 Changes or modification warning.  
Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

§ 15.105 Information to the user.  
Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.  
However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.