


Portable Bluetooth Speaker



NT-F9L

Instruction Manual

Please read all of the instructions carefully and retain for future reference

Safety Instructions 1

1. When using electrical units, basic safety precautions should always be followed.
2. Children aged from 8 years and people with reduced physical, sensory or mental capabilities or lack of experience and knowledge can use this unit, only if they have been given supervision or instructions concerning use of the unit in a safe way and understand the hazards involved.
3. Children should be supervised to ensure that they do not play with unit.
4. Unless they are older than 8 and supervised, children should not perform cleaning or user maintenance.
5. This unit is not a toy.
6. This unit contains no user-serviceable parts. If the unit and any of its accessories are malfunctioning or it has been dropped or damaged, only a qualified technician should carry out repairs. Improper repairs may place the user at risk of harm.
7. Keep the unit away from reach of children.
8. Keep the unit away from heat or sharp edges that could cause damage.
9. Keep the unit away from heat sources, direct sunlight, humidity, water and any other liquid.
10. Keep the unit free from dust etc.
11. Do not immerse the unit in water or any other liquid.
12. Do not operate the unit if it has been exposed to water, moisture or any other liquid to prevent against electric shock, explosion and/or injury to yourself and damage to the unit.
13. Do not use the unit for anything other than its intended use.
14. Do not store the unit in direct sunlight or in high humidity conditions.
15. Do not put objects into any of the openings.
16. Do not play music at excessive volume levels as damage to hearing and/or the equipment may occur. It is imperative to unplug the adaptor after the unit has been used, before it is cleaned and whilst being repaired.
17. To prevent possible hearing damage, do not listen at high volume levels for long periods of time.
18. Warning: Keep the unit away from flammable materials.

Specifications 2

Power Supply : USB 5V / 1A
Output Power : 8W*2
Driver Unit : 4"30*2
Bluetooth Version : V5.0
Storage class : Max Size 32Gb
FM Frequency Range : 87.5-108 MHz
Frequency Response : 80Hz - 2000Hz
S/N Ratio : ≥ 65dB
Rechargeable Battery : Lithium 3.7V 5400mAh
Product Size : 165*110*60*114 mm


Getting Started 3

1. Remove the unit from the box.
2. Remove any packaging from the unit.
3. Place the packaging inside the box and either store or dispose of safely

In The Box 4

Bluetooth Speaker	*1
USB Charging Cable	*1
3.5 mm Aux In Cable	*1
Remote Control	*1
Wireless Microphone	*1
Carry Strap	*1
Instruction Manual	*1

Description of Parts 5



1. Mode	8. AUX IN
2. Prev/VOL-	9. TF Card Slot
3. Play/Pause	10. USB Card Slot
4. Next/VOL+	11. Microphone One Input
5. Equalizer (Two Mode)	13. Microphone Two Input
6. Number	13. DC 5V Charging Input
7. Number	14. Power On/Off Switch

Instructions for Use 6

Bluetooth Operation

1. Power on the speaker.
2. The speaker will be default into Bluetooth mode when first turned on.
3. Turn on the Bluetooth setting of your device and search the pairing name "NT-F9L".
4. Music is ready to play after paired.
5. Long pressing "Play/Pause" button to disconnect Bluetooth connection.

USB/TF Operation

1. Insert USB/TF speaker will play the music directly.
2. Press "Play/Pause" button then press or play the music.
3. During the playback, long pressing the "Next or Prev" buttons to adjust the volume.
4. Press "OK" button to play the song list.

*** Please don't take out USB/TF card while playing, otherwise, USB/TF card will be damaged ***

Aux In Operation

1. Press "Mode" button to AUX-IN mode.
2. Insert AUX-IN cable and connect to your device to play music.

Radio Operation

1. Press "Mode" button to FM Radio mode.
2. Long pressing "Play /Pause" button to run auto scan and save available channels.
3. Press "Prev" or "Next" change to previous and next channel, or press the number button to locate the saved channels, for example, you want to listen to saved channel 12, then press number "1" and "2".
4. Press number to manual searching channels by frequency, for example, you want to search channel frequency 97.1, then press number "0", "9", "7" and "1", channel frequency 107.5, then press number "1", "0", "7" and "5".

Instructions for Use 7

LED Lighting Operation

1. The speaker will be default into LED lighting when power on.
2. Long pressing "0" button to off the LED lighting.

Hands-Free Operation

1. Press "Play/Pause" button to answer the call.
2. Press "Play/Pause" button again to hang up the call.

Record Operation

1. Insert wired microphone or connect with wireless microphone
2. Insert USB stick or TF card which is available with storage.
3. Play the latest insert in priority while power on.
4. Press "EQ" button to enter into record mode, and start recording.
5. Press "EQ" button again to exit record mode after finished recording.

Supplies:

1. Default Mode: BT
2. Mode Switch Sequence: BT→USB→TF→FM→AUX IN
3. Play the latest insert in priority while power on.
4. If the device was inserted with USB/TF/AUX and power on, then USB mode is in priority when restart the device.
5. The maximum volume is level U16, the volume will be automatically limited at level U16 after the speaker is under lower battery status and alerted with lower battery prompt tone.

Instructions for Use 8

FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Radiation Exposure Statement

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter. The equipment should be installed and operated with minimum distance 20cm between the radiator and your body.

Caution

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

