


# Air Cooler

# INSTRUCTION MANUAL



## Air Cooler

Model:CL-1

Thank you very much for using our products. Please read the user manual carefully before use, and keep it for future reference.


Guangdong Invitop Technology Co., Ltd  
B-6F, NO.6 , Xinhua Road, Sanjiao Town, Zhongshan, Guangdong, P.R.C

## CONTENT

Product Overview .....	01
Specification .....	02
Instruction .....	02
Maintenance .....	04
Warning .....	05
Attention .....	05
FAQ .....	06

## PRODUCT OVERVIEW

### Components



-01-

## SPECIFICATIONS

Name	CL-1 Air Cooler
Size	199*154*175mm
Input	DC 5V 1.5A
Power	6W
Working capacity	800ml


## INSTRUCTIONS

### Preparations

Open the tank cover and fill the tank with appropriate water. Close the cover and plug it into the power socket. When the power indicator lights up, the machine enters standby mode.

-02-

### Control Panel



#### ON/OFF button

Turn on/off the machine, the water tank light is not controlled.

#### Mode button

Switch between high and low mode, corresponding indicator light on.

#### Light button

Turn on/off the water tank light, not controlled by the switch button.

-03-

### NOTICES:

- When installing the water tank, make sure the water tank is in place.
- Do not move the filling machine during use.
- Make sure there is no water in the fuselage before handling and moving the machine.
- Please don't stress the wet curtain to avoid damage.
- Using wet curtain for a long time can be yellow, belonging to a normal loss.
- The mode indicator light will be on when the machine is working. If it is not lit up, please press the power button.

### MAINTENCE

- Turn off the power of the machine and unplug the power cord. Open the cover, pour out the remaining water in the water tank and the fuselage, use a clean cloth to clean the product and the water tank (it is recommended to clean the product once two days, if you do not use the product, please clean it before storing it).
- Be careful not to flush the main engine with water, or it will cause the risk of electric leakage and short circuit.
- It is suggested that wet curtain should be used in 3 months or when wet curtain hairs yellow for a large area, please change it.

-04-

## WARNINGS

- Do not put it in the reach of children. Do not place or use it near pets.
- Do not plug in when your hand is wet.
- Do not block the air inlet and outlet.
- When not in use, please pull out the plug.
- This product shall not be disassembled or repaired without authorization. In case of any abnormality during use, the power must be cut off immediately and contact the local manufacturer.
- Do not put your hands or objects into the fuselage.
- Please replace the wet curtain after the power is disconnected and the fan stops.

## ATTENTION

- This product is suitable for clean tap water or pure water.
- Please put it in a horizontal position before using.
- Please be sure to empty the remaining water in the tank after using.
- If not in use for a long time, please unplug it.
- Moisture will be generated in the work of this product, please stay away from valuables or electrical appliances that are afraid of moisture and water.
- Do not add water to the fuselage manually, especially do not add water to the air outlet and air inlet.

-05-

## FAQ

If the above FAQ can not solve your problems and need maintenance, please contact the supplier or after sales service center. Please do not disassemble the machine to maintain by yourself.

SITUATION	REASON
No working	Is the power connected? If not, please plug in the power
	Is the power button of the machine on? If not, please press the power button
Machine leaking	Is the water tank in place? If not, please install it in place
	Is the fuselage inclined, if so please flat it
	Is water in the machine body when moving the machine? If there is water, please move the machine after using it

-06-

**FCC Warning:**  
Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.  
This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:  
(1) This device may not cause harmful interference, and  
(2) This device must accept any interference received, including interference that may cause undesired operation.  
Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:  
-Reorient or relocate the receiving antenna.  
-Increase the separation between the equipment and receiver.  
-Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.  
-Consult the dealer or an experienced radio/TV technician for help.  
This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.