

# **USER MANUAL**

### **Product Instruction**

This product is mainly used to read the data of car engine and emissions, diagnostic car engine trouble, and erase trouble codes.

### **Main function**

This product can diagnosis vehicle health, alarm vehicle security, real-time monitor vehicle health, display the diagnostic values of various vehicle indicators (voltage, engine coolant temperature, fuel correction value, engine load value, etc.) in detail, conduct examination on the car, and read and erase trouble codes, etc.

### **Find OBD interface**

Find the OBD interface in the car. The OBD interface may located in different place for different vehicle models. (Generally located on the underside of the dashboard on the driver's side

of the car, above the accelerator pedal)


### Download APP

Use mobile browser to scan the QR code below or manually enter "[www.elm327.com](http://www.elm327.com)"

iOS	Android
Car Scanner	Torque
You can also search for the software name in Google Play or Apple Store to download	
	


## Download steps

Go to [www.elm327.com](http://www.elm327.com) website



## Download steps

Select the menu to download the software according to the equipment system




## Connection steps

IOS APP "Car Scanner" user manual



Car Scanner


1. Turn on Bluetooth or WiFi according to product properties



Note: iOS users can turn on Bluetooth or WiFi according to product attributes, and Bluetooth products and mobile phones do not need to be paired

## Connection steps

2. Choose "CONNECT"



### Connection steps

3. Select Bluetooth or WiFi according to product attributes



4. Choose OBDII





## Connection steps

5. Wait for the connection to succeed




## Connection steps

Android APP "Torque" user manual




Torque



1. Plug the product into OBD interface in car, turn on the phone Bluetooth and connect "OBD II", the password is 1234 or 0000


## Connection steps

### 2. Select Settings




## Connection steps

### 3. Select OBD2 Adapter Settings




## Connection steps

### 4. Select Connection Type





### 5. Choose Bluetooth or WiFi according to product attributes




## Connection steps

### 6. Choose Bluetooth Device



### Connection steps

7. Return to the main page and wait for the connection to be successful. When the car icon stops flashing, it means the connection is successful (exit the APP and re-enter for a quick link)



## **Warning Statement**

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

**Note:** This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.