

## OneAndDone Pro Remote Control Instructions

The Remote Control Pack contains the following items:


- 1.The remote control unit (gray plastic box).
- 2.wireless remote(white remote) with a 12V battery.

This remote control unit is equipped with a connector for proper connection. Connect the existing battery and motor, please follow the steps below;

1. SAE cable connected to Motor



2. 6.3mm Crimp Terminal Cable Female Connector battery



## OneAndDone Pro Remote Control Command



1. Press the SET button to turn on the unit. When the device is turned on, "Time" will appear on the screen. Use the HR and MIN buttons to set the current time. Then press SET to confirm.
2. After confirmation, "Rotate 1-6" will appear on the screen. Use the HR and MIN buttons to set 6 different motor start times, then press "SET" to confirm. If you want to set less than 6 different start times, use the HR button to toggle until it shows "Off".
3. After confirming the motor start time, "Rotation Time" will be displayed on the screen. Use the HR or MIN button to set the rotation duration to 1-60 seconds and press SET to confirm.
4. Then you will see "Motor Speed" on the screen. Use the HR or MIN button to set the motor speed. Choose from 50%, 75% and 100% (100% recommended for best performance). Then press "SET" to confirm. You have finished setting the timer.

## Wireless Remote Control Instructions



Battery included



Specifications:

Category: Alkaline Battery

Size: 10.22 \* 28.5 mm

Voltage: 12V

Model: 23A12V

Take out of the insulation sheet before using the remote control

Warning: Please keep these and other batteries away from Children.



1. Press the 2 button motor to start for 2 seconds.
2. Press the 5 button motor to start for 5 seconds.
3. Press the 10 button motor to start for 10 seconds.
4. Press the 20 button motor to start for 20 seconds.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.