

Alarm Clock Wireless Charger Model: SY-W0299

I .Function Buttons:



II .Function:

1.Power connection:

- 1.1 Plug the USB-A end of cable into the power adapter while plug Type-C end into the product.
- 1.2 The product will be ready and stand by after all indicators are on.

2.Wireless charging 、USB-A output

- 2.1 Wireless charging output:15W(Max)
- 2.2 Indicator Display:

Power connection successful:Turns off after flashes twice;

Standby:no light on;

Charging:light on

Fully charged:light off (some Apple phones do not support this function)

FOD:light flashes continuously

2.3 USB-A Output: 5V/1A(Max)

3.Alarm Clock Functions:

3.1 Button Functions:

FM、M、SNOOZE、+、-.

3.1 Time System Setting:

Double click M button to setup 12-hour and 24-hour time system;PM will display while 12-hour time system is set.

3.3 Time Setting:

3.3.1 Click M button once to enter hour setting,short press “+/-” adjust hour value ;Long press +/- can be adjusted continuously;

3.3.2 Click M button to enter minute setting after hour setting,short press “+/-” adjust minute value;Long press +/- can be adjusted continuously;

3.3.3 Click M button again to finish time setting.

3.4 Alarm clock and brightness setting:

3.4.1 In standby state, Long press “+”to activate or deactivate Alarm 1,long press “-” to activate or deactivate Alarm 2.Alarm indicator is on while Alarm is activated;

3.4.2 While activated,long press M button to enter Alarm 1 hour setting,short press “+/-”button adjust

hour value ;Long press +/- can be adjusted continuously;

3.4.3 Press M button to enter Alarm 1 minute setting after Alarm 1 hour setting,short press “+/-” adjust minute value;Long press +/- can be adjusted continuously;

3.4.4 After the minute setting completed, click the “+/-” button to select 01 Alarm ring reminder; select 02 Play FM as alarm reminder (The FM reminder will be available after the automatic channel search is completed in advance);

3.4.5 If choose 01 Alarm ring reminder, then click the M button to enter the alarm clock 2 setting, the operation method is the same.

3.4.6 If choose 02 play FM as alarm reminder, then click the M button to enter the selection of FM channel; click the “+/-” button to switch; then click the M button to enter the adjustment of FM volume, click the “+/-” button to increase or decrease FM volume. After the setting of alarm clock 1 completed, then click the M button to enter the setting of alarm clock 2, the operation method is the same.

3.4.7 Alarm rings 3 minute/FM plays 3 minute before automatic switch-off while no any operation.

3.4.8 All buttons are deactivated after the alarm clock rings, press any key to enter the snooze mode.The alarm rings again after 5 minutes,the alarm clock indicator is flashing in Sleepy Mode,Long press “+” or “-” button in the Sleepy Mode to permanently turn off alarm clock 1 or alarm clock 2,Long press the SNOOZE button to turn off the alarm clock of the current day and the alarm clock of the next day is still valid.

3.4.9 The brightness of the clock can be manually adjusted with five levels,click “+” and “-” to adjust the brightness of the digital display. After plugging in,the clock keep the max brightness by default. Press the “-” to decrease the brightness and press “+” to increase the brightness . Press“-”last time to turn off the light of clock display.

3.5 Perpetual calendar&temperature

3.5.1 Short press Snooze button to check the Year+Month+Day,automatically exits after 5 seconds.

3.5.2 Long press the “Snooze”to enter the calendar setting YEAR(No display while standby)→MONTH→DAY;Adjust value with short press +/-;Long press +/- can be adjusted continuously;

3.5.3 Double click the “Snooze” to switch three kinds of standby interface Month/Celsius/Fahrenheit + date.

3.6 Setting the FM Radio:

Note: Please perform the first radio search in an open and unobstructed environment.

3.6.1 Short press “FM” button to turn on or turn off the FM Radio.Please pay attention to extending the receiving antenna of the radio as far as possible to obtain better FM reception. (The number and effect of FM channels accepted are related to the surrounding environment, weather and local FM programs. Please pay attention to confirm before use).

3.6.2 While FM Radio is on, long press “FM” button to search the stations automatically and display the corresponding frequency; After the search is completed,the station codes will be saved automatically.

3.6.3 While FM Radio is on, short press “+” or “-” button to select the radio stations.

3.6.4 While FM Radio is on, long press “+” or “-” button,corresponding increase or decrease of FM volume.

3.7 Eco-power function:

3.7.1 Button cell is only for time keeping.

3.7.2 All functions are out during power disconnection.Functions restored when power is connected.

4.Notice:

Attention: In order to function alarm, wireless charging and USB output work at same time, power shall be connected by a QC3.0 or above power adapters. If connected by a 5V adapter, only 5W wireless

charging and alarm can work together.

4.1 Do not squeeze or collide.

4.2 Do not disassemble or put into the fire, water, to avoid short-circuit leakage.

4.3 Do not use wireless chargers in severe high temperature, humidity or corrosive environments to avoid leakage of damaged circuits.

4.4 Do not place too close to magnetic cards (ID cards, bank cards, etc.) with magnetic strips or chips to avoid magnetic card failure.

4.5 Keep more than 20cm between the implanted medical device (pacemaker, implantable cochlea, etc.) and the wireless charger to avoid potential disruption to medical devices.

4.5 Keep children from the product in case they play the wireless charger as a toy to avoid accidents.

4.6 Keep the wireless charger and receiver device away from water and other liquids.

4.7 To clean the charger, make sure the power supply is disconnected.

4.8 Usage temperature: 0-45℃.

4.9 Usage humidity: 20-85% (40℃)

Warning: This product contains button batteries, which can cause serious or fatal injury within 2 hours if swallowed. Batteries must be kept away from children. If you think the battery may have been swallowed or placed anywhere in your body, seek immediate medical attention.

*Pictures in this manual are all illustration. Final product is subject to fact.

*Inside package: alarm charger, charging cable, User Manual.

*Power adapter is not included. Please purchase or use phone original adapter.

III.Specification:

Input: DC 5V/3A;9V/3A;12V/2A

Output: 15W (MAX)

Charging efficiency: 73%

Charging distance: ≤6mm

USB-A output: 5V/1A(MAX)

Work frequency: 113-205KHz

FM frequency: 87.5 -108MHz

Product size: 161.5*123*57mm

IV.Applicable Devices:

Products qualified with Qi standard.

FCC WARNING

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

To maintain compliance with FCC's RF Exposure guidelines, This equipment should be installed and operated with minimum distance between 20cm the radiator your body: Use only the supplied antenna.