



## Photograph No.1 Peak output power measurement setup

Photograph No.2 Spurious emissions measurement setup in the anechoic chamber below 30 MHz


Photograph No.3 Spurious emissions measurement setup in the anechoic chamber in 30 -1000 MHz



Photograph No.4 Spurious emissions measurement setup in the anechoic chamber in 1-18 GHz



Photograph No.5 Spurious emissions measurement setup in the anechoic chamber in 18-40 GHz






Photograph No. 6 Spurious emissions measurement setup at the OATS above 40 GHz

Photograph No. 7 Spurious emissions measurement setup at the OATS above 40 GHz, EUT close view





Photograph No.8 Frequency stability and OBW measurement setup



Photograph No. 9 Conducted emissions measurement setup on AC power lines