WELCOME TO LEXI

User guide

Operation

1. Plug in the DC24V 1A adapter (provided in #20001) to the control box. 2. Connect the LEXI Strip light to the control box.

3. In order to add new devices to your Lexi Mobile App, first follow the instructions for connecting your Lexi Portable Hub to your wireless network. 4. Power on your light(s). Once you do, you will see the light(s) flashing with cool white color.

5. Select "ADD NEW DEVICE" on the LEXI Mobile App and follow the instruction to complete adding the light(s). During this process you'll see the light transition to warm white flashing as it goes through the association process until it stops flashing and remains on warm white color.

6. Your light(s) has been added to the LEXI Mobile App successfully and ready to use.

7. To learn more about how to use your Lexi lights, please an to

DISPOSAL OF YOUR OLD PRODUCT:

Your product is designed and manufactured with high quality materials and component, contains nonremovable Lithium-Ion batter, which can be recycled and reused. When this crossed-out wheeled bin symbol is attached to a product it means the Temperature (storage): -25...60°C Relative product is covered by the European Directive 2002/96/EC.

CLEANING AND MAINTENANCE: Do not clean when the product is on and Please find out for yourself about the connected to mains power. To avoid scratching, the product should only be cleaned with a soft dry cloth. Do not use

WIRELESS SPECIFICATION:

Channel: 0 -39 channels

cleaning agents.

802.15.4

BLE Frequency: 2402-2480MHz

ENVIRONMENTAL SPECIFICATION:

Temperature (operation): -5...40°C

humidity: 5-90% non-condensing

Wireless communication protocol: IEEE

User Manual

Item: #20001 - Strip Light Smart Color &

Tunable White

PLEASE KEEP THIS PACKAGING FOR FUTURE **REFERENCE AS IT CONTAINS IMPORTANT** INFORMATION.

local separate collection system for electrical and electronic products. Please equipment. act according to your local rules and do not dispose of your old products with your - Shielded Cables must be used with this normal household waste. The correct disposal of your old product will help prevent potential negative consequences for the environment and human health.

WARNINGS AND CAUTIONS:

- NOT FOR USE IN ENCLOSED LUMINAIRES - Only use the adapter supplied: using a different adapter can damage the product.
- This device is not intended for use with emergency exits.
- Keep away from liquids and humidity.
- The product is for indoor use only. Do not the dealer and a description of the use in wet locations, directly exposed to water or outdoors.
- This product is not a toy designed to be played with by children.
- Do not place on hot surfaces.
- Do not be exposed to extreme temperatures, direct sunlight and moisture.

- For safety reasons and under the terms of the warranty, none of the enclosed devices should be opened.

FCC WARNING AND CAUTION:

- This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. - Changes or modifications to this unit not

expressly approved by the party responsible for compliance could void the user's authority to operate the

FCC ID : 2ATOT20001

unit to ensure complaince with the Class B FCC limits

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 radio/TV technician for help. of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

- Shielded Cables must be used with this unit to ensure complaince with the Class

WARRANTY:

LEXI provided one-year warranty is valid if the product is used in accordance with the instructions and for its intended purpose. Claims will only be accepted on Bluetooth and location turned on. submission of the original proof of purchase (invoice, sales slip or receipt) stating the purchase date, the name of product with product ID labeled at the products.

The LEXI's warranty lapses if:

a. Anything has been changed, crossed out, deleted or rendered illegible on the purchase docket or product description. connections or abuse.

c. A defect is caused by extreme circumstances not inherent to the product, for example, lighting, flooding, fire, incorrect use or negligence. d. The product has been opened or disassembled.

e. using a different adapter other than we provided

TROUBLESHOOTING

- Ensure your device is within 45 feet of the Lexi Portable Hub without obstacle - Ensure your smart phone has both

- Check the power On/Off switch is located at On position.

- Make sure there is a good connection of the power supply to the control box - Make sure there is good connection of the control box and the Strip Light.

- Confirm your smart phone is paired with the LEXI Portable Hub

- To un-pair the lights turn the light on/off 6 times in quick succession using the Lexi b. The failure is caused by damage, faulty Mobile App. Afterwards, you'll see a cool white flashing. (A warm white will be flashing at the 5th power cycle which is a warning signal for you. If you don't want to un-pair it, stop the power cycle. The light will go back to the last state). Then, re-pair this light in the User Guide section.

Remarks:

For Item #90017 Extension Strip light, it does not contains adaptor.

This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.

- Increase the separation between the equipment and receiver.

- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

- Consult the dealer or an experienced

