

60mm

83mm

i-box
PodiumPortable Bluetooth Speaker
with Wireless Charging

Introduction

The i-box Podium is a Bluetooth speaker designed around your phone.

Not only does it play music for up to 18 hours, it also has a built-in wireless charger to keep your phone powered up.

The Podium also works as a handy phone stand - great for watching movies, looking at recipes, making video calls and much more.



i-box www.iboxstyle.com

Podium | 02

 Caring for your Speaker
Important Safety Information

Important - Please read these instructions fully before installing or operating your speaker.

Keep away from flame sources such as lighted candles. Do not expose to dripping or splashed fluids. Objects filled with liquids, such as vases, should not be placed close to the speaker.

The unit should not be exposed to direct sunlight, very high or low temperature, moisture, vibrations, strong magnetic fields, high frequencies and dusty environments.

Do not place the product in enclosed bookcases or racks without proper ventilation. Ventilation should not be impeded by covering the ventilation openings with items, such as newspapers, table-cloths, curtains, etc.

This product contains a built-in lithium battery. It must be used and charged properly. Improper use can cause the battery to catch fire or explode resulting in serious or fatal injury.

Never attempt to insert wires, pins or other such objects into the vents or openings of the unit.

Do not disassemble or modify the speaker; there are no user serviceable parts.

If the speaker is damaged in anyway or malfunctions do not use. Consult a qualified service engineer.

Do not use abrasives, benzene, thinner or other solvents to clean the surface of the unit. To clean, wipe with clean soft cloth and a mild detergent solution.

This product contains a Li-ion battery and should be disposed of appropriately. Do not dispose of it with household waste at the end of its life cycle; hand it over to a collection centre for the recycling of electrical and electronic appliances with batteries. Please check with your Local Authority for recycling advice.



Contents

1. Safety information	
Introduction	2
Safety information	3
2. Getting to know your speaker/charger	
Controls & features	5
3. Getting started	
Charging your speaker	6
Bluetooth connection	6
Bluetooth play operation	6
AUX IN connection	7
AUX IN operation	7
Wireless charging	7
Wireless charging problems	7
4. Other Information	
Specifications	8
Disclaimer	8
Declaration of conformity	8
Technical support	8

i-box www.iboxstyle.com

Podium | 04


Box Contents

i-box Podium with micro USB charging cable

Getting to know your speaker/charger

Before you get started please read the safety information on pages 2-3.


Top - Control Panel



Buttons

1. Power On/Off
2. Play/Pause
3. Reduce volume/Previous track
4. Increase volume/Next track


Front - Wireless Charging Panel & LEDs



Features

5. Phone stand
6. Power/Wireless charging LED
7. Bluetooth LED
8. Centre of wireless charging area

Back - Connections



Connections

9. 3.5mm AUX IN socket
10. DC Micro USB power socket

05 | Podium

i-box

Charging your Podium speaker

Your Podium speaker has a built-in non user-replaceable Lithium battery. For best results, the first time you use the Podium, let it charge for 4-5 hours until fully charged.

1. Connect the micro USB cable supplied to the Podium's Micro USB socket (10) and to a powered USB port on a USB charger or computer.
2. LED (7) will lit green while the battery is charging. The Charge LED (7) light will turn off when the battery is fully charged.
3. Disconnect the USB cable when the battery is fully charged.

Please Note:

The speaker will charge when connected to a 1A, 5V USB output but will charge much faster if connected to a 2A, 5V USB output.

Bluetooth connecting & disconnecting

1. Long press the (1) power button to switch on your Podium. You will hear a "power on" message. You will next hear "Bluetooth mode" and then "pairing" messages. The Bluetooth LED (7) will flash blue.
2. Place the device you want to pair with your Podium within 1m of it, enter your device's Bluetooth menu and select "i-box Podium" in the device list. When your Podium and device are paired, the Bluetooth LED (7) will stop flashing and stay lit blue and you will hear the message "connected".

Once paired with a device the Podium will reconnect automatically when switched on if the paired device is within range.

Bluetooth play operation

1. Short press +/- (4/3) to increase or reduce the volume level.
2. Long press + (4) to play the next track or long press - (3) to select the previous track.
3. Press (2) to play or pause the track.

During Bluetooth playback the Bluetooth LED (7) will flash blue. Please Note: Your Podium will notify you if you receive a call while it is connected to your phone but does not have Handsfree capability. Please answer your phone normally when it is connected to the Podium.

Power Saving

If there is no Bluetooth audio input for 5 minutes your Podium speaker will automatically power off.

i-box www.iboxstyle.com

Podium | 06

AUX IN connection and operation

For audio sources without Bluetooth capability you can connect via the 3.5mm AUX IN socket (9) on the back of the Podium.

1. Use a 3.5mm audio lead to connect an audio source to the AUX IN socket (9). On connection you will hear an audio message confirmation, "AUX mode".
2. Select and play tracks using the controls on your audio source.
3. Short press +/- (4/3) to increase or reduce the volume level. Press (2) to mute the sound (the track will continue to play).


Wireless charging

If you have a phone with wireless charging capability you can use your Podium to charge it.

Thanks to the smart positioning of the charging pad it is easy to watch movies, look at recipes, make video calls and much more while charging.

1. Place your smartphone centrally on the phone stand (5) as shown opposite.
2. The battery charge status can be seen on the display of your phone and the wireless charging LED (6) will stay a constant green during wireless charging and switch off when charging is complete.

Please Note: You can still charge your phone when the speaker is switched off, as long it has a USB power connection. If the speaker is switched off and there is no USB power connection your phone will not charge.



If problems occur when charging or if charging does not start

- Remove your smartphone from its case if the thickness of the case exceeds 5mm or if it has a metal composition.
- Phones that are capable of wireless charging may need to be placed slightly off centre. The built-in wireless receiver may not be centred inside the phone. This varies by brand/model.
- The charging time varies depending on the charging capacity of the battery and its current residual capacity.
- The components may heat up during the charging process. They will slowly cool down again after the charging process.

07 | Podium

i-box

Specifications

Power Input: 5VDC
Lithium Battery Output: 4,000mAh
Speaker Output: 2 x 3W RMS
Wireless Charging Output: 5W
Music Playback: Up to 18hrs

Disclaimer

Updates to Firmware and/or hardware components are made regularly. Therefore some of the instructions, specifications and pictures in this documentation may differ slightly from your particular situation. All items described in this guide are for illustration purposes only and may not apply to your particular situation. No legal right or entitlements may be obtained from the description made in this manual.

Declaration of conformity

Hereby, Philex Electronic Ltd. declares that the radio equipment model i-box Podium Bluetooth Speaker with Wireless Charging for wireless reception in domestic premises is in compliance with the Radio Equipment Directive 2014/53/EU. The full text of the EU declaration of conformity is available at the following internet address: www.philex.com/dec.

Technical support

For further help, advice, information or live chat visit www.iboxstyle.com



Waste electrical and electronic products should not be disposed of with household waste. Please recycle where facilities exist. Check with your Local Authority for recycling advice.



© Philex Electronic Ltd 2019. v1.1
Kingfisher Wharf, London Road,
Redford, MK42 0NX UK
Made in China

风琴折四折页：
成品尺寸：240x83mm
材质：128g铜版纸

FCC Statement

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

-- Reorient or relocate the receiving antenna.

- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device and its antenna(s) must not be co-located or operation in conjunction with any other antenna or transmitter.

The device has been evaluated to meet general RF exposure requirement. in portable exposure condition without restriction.