


B98



BLUETOOTH SPEAKER




User Guide

What is in the box

- 1 X LED COLOR CHANGING Speaker
- 1 X Micro USB Cable
- 1 X User manual

Product Overview

1. Lighting mode
2. Power ON/OFF
3. Micro USB port
4. Play/Pause/Answer/refuse
5. Microphone



Charging the Bluetooth speaker

Before first use, please charge the Bluetooth speaker. Plug the provided charging cable into the speaker and an active computer USB port or a USB AC adapter that is plugged into an active wall outlet. The LED light is red color and will be die out after full charged.

Remark: If not using the speaker for a long period of time, keep the internal battery charged (charge once every 3 months). This will extend the life of your battery.

Bluetooth Instruction

(Note: The Bluetooth code is B98, pair code: 0000)

Make sure the Bluetooth function is available on your cell phone. Specific pairing procedures will be different depending on different cell phone. For detailed information, please refer to your cell phone User Guide.

- If no device connection is made within 10 minutes of the Speaker being switched on, the Speaker will automatically switch to power off to save power.
- After a successful pairing, devices will memorize each other. It will be connected automatically after turn on.

- Keep the distance between the cell phone and the Speaker within 10m (for pairing only).
- Turn on the Speaker.
- The tone prompt will sound and the LED light will flash blue. The unit will automatically enter into pairing mode.
- Activate the Bluetooth function of the cell phone to search for the Bluetooth devices. After finishing the search, select "B98" in the device list displayed.
- The Bluetooth speaker is ready for use.
- During the time, if want use another cell phone to connect the speaker, Long press play/pause button to disconnect current cell phone. Then open the Bluetooth and connect with the speaker in another cell phone.

Speaker Controls

ON/OFF
Turn ON/OFF.

PLAY/PAUSE/ANSWER/REFUSE THE CALL

Press play/pause button to play/pause during play music.
Press play/pause button to answer the call, press it again to hang up.
Long press play/pause button to refuse the call.
Double press play/pause button to call back the last number.
To hang up the call press it again.

Remark: Please face on the Microphone hole to answer the call, to avoid the poor call quality.

Lighting mode

Note: The lighting mode can be use during playing music.
Mode 1: Press light icon, breathing light
Mode 2: Press light icon, Seven kinds of monochromatic light automatic switch
Mode 3: Press light icon, Save white light
Mode 4: Press light icon, Colors lights follow the rhythm of the music
Mode 5: Press light icon, Turn off the lights

Specifications

Function: Bluetooth, Hands free, LED light
Bluetooth version: 5.0
Power output: 3W 4Ω
Speaker: D45mm(120HZ-20KHZ)
Lithium polymer battery: 500mAh
Dimension: 71*70*70MM
Single weight: 147g
SNR: 90±3dB
Charging Time: 1.5hours
Play Time: 3hours (max volume)

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference receiver including interference that may cause undesired operation.

Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
-- Reorient or relocate the receiving antenna.
-- Increase the separation between the equipment and receiver.
-- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
-- Consult the dealer or an experienced radio/TV technician for help.

This device and its antenna(s) must not be co-located or operation in conjunction with any other antenna or transmitter.
The device has been evaluated to meet general RF exposure requirement. in portable exposure condition without restriction.

成品尺寸: 76.2x95.25mm

128g铜版纸 双面印刷